

Model 4010 Text Display User's Guide



Doc. No. 4010UG Revision B May 2002

Copyright © 2002 Control Technology Corporation All Rights Reserved. Printed in USA The information in this document is subject to change without notice. The software described in this document is provided under license agreement and may be used or copied only in accordance with the terms of the license agreement.

The information, drawings, and illustrations contained herein are the property of Control Technology Corporation. No part of this manual may be reproduced or distributed by any means, electronic or mechanical, for any purpose other than the purchaser's personal use, without the express written consent of Control Technology Corporation.

The following are trademarks of Control Technology Corporation:

- Quickstep
- CTC Monitor
- CTC Utilities

Windows is a trademark of Microsoft Corporation.

Contents

EU Information SELV Circuits Environmental Specifications Preventive Maintenance and Cleaning	vii vii vii vii vii
Notes to Readers	1
Related Documents	2
Contacting Control Technology Corporation	
Your Comments	

1 Introduction

Introduction to the Model 4010 Panel	7
What you need to get started	8
Hardware	8
Software	8
Need Help?	8
On-screen Help	8
Controller Help	8
Model 4010 Description	9
CTC Cables and Accessories	10
Front Panel Features	11
Operator Controls and Indicators	11
PLC Message LED	11
Control Pushbuttons	12
Function Pushbuttons	12
Pushbutton LEDs	12
Annunciator Lamps	12
Data Entry (Keypad) Pushbuttons	
Character LCD Display with LED Backlight	
Messages	13
Rear Panel Indicators	14
Specifications	14

2 Hardware Installation

Custom Labels	17
Create Custom Labels	17
Install Custom Labels	17
EMI Noise Filter Installation	
Mounting	19
DIN Clip Mounting	
Connections and Wiring	
Power Connector	
Serial Port	
Connect a Programming PC	
Connection Diagrams	
=	

3 Learning the Features

Learning the Features	
Memory Mapping / Controller Data Registers	
Controller Data Types	
CTC Controller Registers: R1 – R65535	
CTC Data Table Locations: D1,1 – D65535,255 (Drow#,c	ol#) 27
CTC Status: S0-S3	
Pushbuttons	
LEDs	
Example when using Panel Set & PLC Release Option fo	or a Function
Pushbutton:	
Annunciator Lamps	
Controller Message Registers	
Embedded Data Registers	
PLC Controlled Decimal Point	
DATA 2 (READ Only)	
DATA 3 (READ only)	
Controller Messages and Local Messages	
Static Messages	
Dynamic Messages	
Embedded Data Values	
Interactive Messages (with an embedded DATA 1 value.	onlv) 33
Passwords	
Displaying Controller Messages	
Static Message Operation	
Dynamic Message Operation	
Interactive Message Operation	
Arrow Adjustment Entry	
Numeric Keypad Entry	
Annunciator Lamps	
PLC Message LED	
Displaying Local Messages	
Local Message Menu Structure Example	
v	

4 Tutorial

Model 4010 Panel Setup	41
SETUP Mode	41
Adjust Display Contrast	41
Internal Software and Hardware Revisions	41
Preparing for Configuration	41
Installing QuickText Programming Software	42
Planning the Project using Application Worksheets	43
Tutorial – Creating the Project using QuickText	
Programming Software	48
Tutorial – Configure a Controller	57
Testing the Project	60

5 Configuration

Configuration	63
Configure a New System	63
Configure Existing System	78
Connect to Panel, View Panel Status and	
Firmware Version	79
Upgrade Firmware	80
Fixing a downloading error	82

6 Maintenance and Troubleshooting

Maintenance	
Fuse Reset	
Precautions	85
Screen Overlay / Chemical Compatibility	85
Screen Overlay Cleaning	
Gasket Replacement	
Troubleshooting	
Panel Configuration Problems	
Controller Errors	
Pushbuttons, LEDs, and Messages	89
Frequently Asked Questions (FAQs)	

A Application Worksheets

Norksheets

B Wiring Diagrams

Wiring Diagrams	105
Panel to Controller Connection Diagram	105
Panel to PC Connection Diagram	105
Communication Connector (J1, D-sub 15-pin female)	106

C Error Messages

CTC Driver Error Messages	109
Model 4010 Panel Error Messages	110
QuickText Programming Software Error Messages	111
PLC DLL Error Messages	111
Communication Error Messages	111
PLC Address Error Messages	113
Message Error Messages	114
Miscellaneous Error Messages	114

EU Information

The Model 4010 Panel is manufactured in compliance with European Union (EU) Directives and carries the CE mark. The 4010 Panel has been tested under CE Test Standard #EN55011, and is listed under UL File #E209355. The following information is provided to comply with EU documentation requirements.

> Note

Products with CE marks perform their required functions safely and adhere to relevant standards as specified by EU Directives provided they are used according to their intended purpose and that the instructions in this manual are adhered to. The protection provided by the equipment may be impaired if this equipment is not used in accordance with this manual. Only replacement parts supplied by Control Technology Corporation should be used.

SELV Circuits

All electrical circuits connected to the communications port receptacle are rated as Safety Extra Low Voltage (SELV).

Environmental Specifications

Operating Temperature	0 to 45 °C
Storage Temperature	–20 to +70 °C
Operating Humidity	10-95% R.H., noncondensing
Air Composition	No corrosive gases permitted

Preventive Maintenance and Cleaning

No preventative maintenance is required. The 4010 Panel overlay should be cleaned as needed with warm, soapy water. See Chapter 6, Maintenance, for a list of compatible/incompatible chemicals and compounds.

This page is intentionally left blank.

Notes to Readers

The Model 4010 User's Guide provides the following information:

- Introduction Lists the hardware and software you need to get started. Discusses how to get help with questions or problems you might encounter through Onscreen Help and Technical Support. Provides you with a table listing the various models, their part numbers and special features. Lists the important features of the 4010 Text Display. Lists the part numbers for controller cables and the programming cable. Tells how to install programming software.
- Hardware Installation Provides instructions on how to install custom labels and the EMI Noise Filter. Discusses two mounting techniques — stud mounting and DIN clip mounting. Provides outline dimensions and a mounting template. Provides you with instructions on connecting the unit to power, a PC, and a controller.
- Learning the Features Provides an overview of the panel features. Local and PLC Messages are described, along with types of Messages and Embedded Data Variables (DATA 1, 2, and 3).
- **Tutorial** Provides instructions to create an example project. Takes you through the steps necessary to create a 4010 Panel project using the programming software and application worksheets. Shows you how to transfer a project to the panel.
- **Configuration** Step-by-step instructions for configuring the 4010 Panel with the QuickText Programming Software.
- Maintenance and Troubleshooting Instructions for maintaining the 4010 panel are provided. The Troubleshooting section helps diagnose problems you might encounter when installing or operating the panel.
- **Appendix A** Application Worksheets are provided to help you plan and implement your system configuration.
- Appendix B Wiring diagrams for several controller cables are provided.
- **Appendix C** Error Messages for controller drivers, 4010 Panel, and QuickText Programming Software.

Related Documents

The following documents contain additional information:

- For information on Quickstep, refer to the *Quickstep*TM Language and Programming Guide or the *Quickstep*TM User Guide.
- For information on the controller registers, refer to the *Register Reference Guide* (available at www.ctc-control.com).
- For information on Microsoft Windows or the PC, refer to the manuals provided by the vendor.

Formatting Conventions

The following conventions are used in this book:

ALL CAPS BOLDFACE	Identifies DOS, Windows, and installation program names.
Boldface	Indicates information to be entered, an action to be per- formed, or a selection to be made on a dialog box or menu.
Italics	Indicates a word requiring an appropriate substitution. For example, replace <i>filename</i> with an actual file name.
Text_Connected_With_Underlines	Indicates symbolic names used in Quickstep programs. Step Names are ALL_CAPITALS. Other symbolic names can be Initial_Capitals or lower_case.
Small Caps	Identifies the name of Quickstep instructions in text.
Courier font	Identifies step names, comments, output changes, and Quickstep instructions appearing in the Quickstep edi- tor.
Art Code 2217F1	Identifies the file name of a particular graphic image.

Contacting Control Technology Corporation

Control Technology Corporation is located in Massachusetts. Our business hours are 8:30 AM to 5:00 PM. EST (Eastern Standard Time).

Contact Method	Address or Number						
E-Mail:							
Technical Support:	help@ctc-control.com						
Technical Publications:	techpubs@ctc-control.com						
Website:	www.ctc-control.com						
Telephone:	508.435.9595 and 800.282.5008						
FAX:	508.435.2373						
Mail:	Control Technology Corporation						
	25 South Street						
	Hopkinton, MA 01748						

Errata Sheets

Refer to the Support area of Control Technology's web site (www.ctc-control.com) for any errata information on this product.

Your Comments

Suggestions and comments about this or any other Control Tech document can be e-mailed to the Technical Publications Group at techpubs@ctc-control.com.

This page is intentionally left blank.

Introduction

Introduction to the Model 4010 Panel	7
What you need to get started	8
Model 4010 Description	9
CTC Cables and Accessories	10
Front Panel Features	11

This page is intentionally left blank.

Introduction to the Model 4010 Panel

The Model 4010 Panel provides a man-machine interface to your controller automation system. The panel provides features such as 5 user-defined pushbuttons with LED indicators, annunciator lamps, arrow adjust buttons, a numeric keypad, and a built-in menu system. The panel communicates with a controller using RS-232C serial communication. Configuration software and panel programming are covered in chapter 5 of this guide.

The panel allows you to configure up to 256 20-character text strings configured as PLC messages and local messages. Local messages are internal panel messages that the operator can scroll in a menu tree hierarchy. PLC messages are displayed when prompted from the controller program. A PLC Message LED illuminates whenever a controller message is being displayed. Either message type can have up to three embedded data variables, one of which can be edited by using the arrow adjust buttons and the numeric keypad.

The panel has sealed membrane function pushbuttons that allow you to trigger controller actions with the push of a button. These pushbuttons are used for input signals to the controller. Each pushbutton can be configured to function as one of three switch types:

- ALTERNATE-keeps its current state until the button is pushed again
- MOMENTARY—is activated only while the button is being pushed
- PANEL SET AND PLC RELEASE —sets a bit in the controller when pressed and is reset by either the controller program or by pressing the button again.

The LCD display window supports two message lines that can display up to 20 characters each. The messages are programmed using the QuickText Panel Programming Software. The message control type may be either **static**—text displays that have NO embedded data, **dynamic** —text messages that include embedded data (READ access only), or **interactive** — text messages that allow the operator to enter data, or change values that are stored in the controller registers (READ/WRITE access).

The panel has a 12-key numeric keypad for entering values in an interactive message. A **decimal** and **ce** (clear entry) button are included. There are 3 annunciator lamps above the LCD display window. Each lamp has a tri-color indicator (red, amber, or green) that is controlled through the Quickstep program.

What you need to get started

Hardware

- Model 4010 Panel
- 24 VDC power supply
- Programming cable (PN 4071-CBL)
- RS-232C adapter and cable (PN 2880G and 2881)
- CTC automation controller
- PC requirements:
 - IBM or compatible PC (486 or better) with a mouse and separate serial port
 - VGA display with at least 800 x 600 resolution (1024 x 768 recommended)
 - Standard Windows 95/98 (Second Revision)/NT4.0/2000 requirements
 - CD-ROM Drive

Software

• QuickText Programming Software (PN 4071)

Need Help?



Note

Section 6, Maintenance and Troubleshooting, should be able to help you with most of the problems you might encounter.

On-screen Help

One of the most important features of the QuickText Panel Programming Software is the availability of context sensitive onscreen help. To access the Help windows, simply press the F1 function key while on the topic where you need help or click on HELP in the main menu bar. For example, if you need help while working with panel configuration, press the F1 function key when that dialog box is open and a pop-up HELP window will be displayed.

Controller Help

If you need help with the controller-to-4010 Panel Interface, see Appendix C or consult the QuickText Programming Software Help. The CTC controller driver has a Help topic that lists the error messages and provides an explanation for each. Also, for controller-to-4010 Panel wiring diagrams, see Appendix B or the QuickText Programming Software Help topics.

Model 4010 Description

The Model 4010 Text Display (Figure 1-1) provides a low-cost, easy-to-use operator interface alternative for your controller system. With easy-to-configure Windows-based software and simple installation, you can be connected and running in minutes. The 4010 display has the following features:

- 2 lines by 20 characters LCD display
- Character height of 0.22" (5.55 mm)
- Stores up to 256 20-character messages
- 5 user-defined function pushbuttons and LEDs
- 4 control pushbuttons
- 12 key numeric keypad
- 3 annunciator lamps (each can illuminate in red, amber, or green)
- Up to three embedded controller data variables per message
- Built-in menu system
- EMI-filtered power supply to reduce communication problems

Figure 1–1. Model 4010 Features



CTC Cables and Accessories

Table 1–1 lists part numbers for cables, programming software, and other accessories.

Table 1–1.	Cables	and	Accessories
	Cables	anu	110003501105

Part Number	Description							
4071-CBL	Programming cable							
2880G	RS-232 adapter							
2881	RS-232 cable							
4071	QuickText programming software							

Front Panel Features

In this section, we will describe the front panel features of the Model 4010 Panel (Figure 1–2). Descriptions of the PLC Message LED, Pushbuttons, Pushbutton LEDs, Annunciator Lamps, controller messages, and local messages are provided. To understand the features, see Chapter 3, Learning the Features. For a demonstration of how to program the panel indicators and controls, please refer to Chapter 4, Tutorial.

Operator Controls and Indicators

The 4010 Panel has sealed membrane pushbuttons for operator interface with a controller. Pushbuttons may be used to begin events or tasks within the controller, such as Start/Stop Control. Pushbutton inputs can be monitored for ON/OFF conditions in your controller's Quick-step program. The 4010 Panel Pushbuttons are Control Pushbuttons, Function Pushbuttons, or Data Entry (Keypad) Pushbuttons.



Figure 1–2. Controls and Indicators

PLC Message LED

This LED (Figure 1–3) will illuminate to indicate that the controller has triggered a message that will be displayed in the LCD window. The pushbuttons are disabled for 3 seconds after a controller message is displayed to ensure that the operator sees the message. The LED will turn OFF when the operator presses the escape pushbutton, thereby acknowledging message received. Press escape again and the controller message will re-display.





Control Pushbuttons

There are 4 Control Pushbuttons (Figure 1–4) on the front panel. These buttons consist of an esc (escape), s (UP Arrow), t (DOWN Arrow), and enter pushbutton.

Figure 1–4. Control Pushbuttons



The arrow buttons are used to scroll through local messages or to change a value within an interactive message. As the operator presses the buttons, the numeric value will increment or decrement, respectively. As it is adjusted, the value will not be updated in the controller data register until the enter pushbutton is pressed. When completed, the operator will press the enter pushbutton and the value will be written to the controller. Press esc to abort or cancel the adjustment without writing the value to the controller.

Function Pushbuttons

There are 5 Function Pushbuttons (Figure 1–5) that are user-defined. They may be configured as one of three "switch" types; Alternate, Momentary, or Panel Set & PLC Release. They are configured as discrete input signals to the controller. These pushbuttons are labeled F1 through F5 or may be custom labeled to suit their function or application.

Figure 1–5. Function Pushbuttons



Pushbutton LEDs

There are LEDs located above each of the user-defined pushbuttons (Figure 1–5). These LEDs can indicate if the pushbutton status condition is ON or OFF, or they can be controlled by the controller. You may choose the LED Control while configuring your panel (see Configuration, Chapter 5). There are three different controls—By Button, By Button & Flash, or By PLC, that will determine LED response when the pushbuttons are pressed.

Annunciator Lamps

The Model 4010 contains 3 tri-color Annunciator Lamps (Figure 1–6) above the LCD message window. Each of these lamps may be programmed to illuminate in green, amber, or red and may be labeled to fit your application. The lamps are turned ON and OFF through your controller's Quickstep program. They are configured with QuickText Programming Software and may be configured to display status or the condition of any operation being controlled within the controller.





Data Entry (Keypad) Pushbuttons

The Model 4010 also features a numeric keypad (Figure 1–7).

Figure 1–7. Keypad Pushbuttons



Use this keypad to enter or change embedded data values. To update or enter a data value, the enter button must be pressed to select the data value. Then you may use the numeric keypad or the Up Arrow (increment) or Down Arrow (decrement) to adjust the value. For the controller to acknowledge the change in value, you must press enter again (sends the updated value to the controller.) The CE (Clear Entry) button is used to clear, or set back to zero, the current value.

Character LCD Display with LED Backlight

Figure 1-8. LCD Display



Messages display in the Character LCD Display Window (Figure 1–8) with LED Backlight. The LCD window supports two line by twenty characters.

Messages

Controller Messages can be programmed to display controller register values and allow the operator to change a controller register value. Up to 3 data variables can be programmed to display in each message. The messages are entered using QuickText Programming Software. Up to 256 controller messages may be configured and stored in the 4010 Panel (Local Messages take away from the 256 Total Messages). Controller messages are numbered 1 to 256. The message control type may be static text, dynamic, or interactive. The controller logic program controls which messages are displayed. The PLC Message LED illuminates when a controller generated message is being displayed.

Local messages are also displayed in the LCD Display Window. Local messages provide pertinent information or instructions to the operator and are displayed in a menu hierarchy. They can also be programmed to display values from a controller register that the operator may change using the 4010 Panel control buttons. You may create folders to group messages pertaining to the same topic. Local messages and folders can be grouped in up to 3 levels using the QuickText Panel Programming Software. The first character in a folder message display is a "+" or "-" indicating folder status (closed or open). The next 19 characters of the display are for the folder text. For messages, all 20 characters are used as message text. Local messages allow the operator to select and initiate user-defined interaction. See Chapter 3, Learning the Features, for more information.

Rear Panel Indicators

- **TXD LED**—This LED (Figure 1–9) will toggle "on" and "off" to signal activity on the transmission line.
- **RXD LED**—This LED (Figure 1–9) will toggle "on" and "off" to signal activity on the receive line.

Figure 1–9. Rear Panel Indicators



Specifications

Display type:	Character LCD, 2 lines x 20 characters with LED backlight, 3 tri-color annunciator lamps (red, amber, or green) 0.4" x 0.75"
Character height:	0.22 in (5.55 mm)
Keypad overlay:	5 function, 4 control, and 12 data-entry pushbuttons
Service power:	24 VDC (20-30 VDC operating range)
Power consumption:	5.5 W @ 24 VDC
Inrush:	< 1 A with 50 ms rise time to 30 VDC
Fuse:	Auto-reset (0.65 A polyfuse)
Enclosure:	NEMA 4, 4X (indoors)
Agency approvals:	UL, CUL, and CE
Operating temperature:	0 to 45 °C (32 to 113 °F)
Storage temperature:	-20 to +70 °C (-4 to +158 °F)
Humidity:	10–95% R.H. (noncondensing)
Electrical noise tolerance:	NEMA ICS 2-230 showering arc, ANSI C37.90a-1974 SWC Level C Chattering Relay Test
Vibration:	5 to 55 Hz 2G for 2 hours in the X, Y, and Z axes
Shock:	10G for under 12 ms in the X, Y, and Z axes
Serial communications:	Download/Program/Controller Port – RS-232 15-pin D-sub female
External dimensions	5 x 10 x 1.6 in (127 x 254 x 40.6 mm)
Weight:	14 oz.

Hardware Installation

Custom Labels	17
EMI Noise Filter Installation	18
Mounting	19
Connections and Wiring	22

This page is intentionally left blank.

Custom Labels

Create Custom Labels

You may create custom labels for the Model 4010 Panel Function Pushbuttons and Annunciator Lamps that are particular to their function within your application. The labels slide into an existing slot in the panel overlay so that the text or numbers you have printed will rest over the pushbuttons or annunciator lamps.

A Microsoft Word® document (EZ-TEXT_INSERTS.doc) was installed in the QuickText Program folder on your computer when you installed your programming software. You must have Word installed on your computer to open this document. This document will help you create your labels. Two sheets of cover stock and a sheet of transparent film have also been shipped with your panel.

Install Custom Labels

Note

A 1/2-inch x 4-inch flat metal tool (ramp tool) is shipped with each unit to aid in the installation of the label inserts.

To install the pushbutton or annunciator lamp labels into the slots, perform the following steps.

- Carefully remove rubber trim mold from panel front to access label slots. (The trim has a barbed retaining rib that is pressed securely into a channel in the front panel housing.) The ramp tool can be used to help lift the trim.
- 2. The recessed slot(s) where the labels are inserted should now be visible.
- 3. Remove the factory installed label insert.
- 4. Use the corner of the ramp tool to lift the top layer of the overlay, just enough to start the custom label into the slot. Hold the overlay up with the ramp tool and start the custom label into the slot.
- 5. Once the label has been started into the slot, move the ramp tool behind the label insert and use as a ramp to guide the label insert into the slot until properly positioned.
- 6. Push label tab down into trim channel with the ramp tool.
- 7. Repeat this procedure for the annunciator lamp label, if required.
- 8. Replace the rubber trim by firmly pressing the barbed rib into the molded channel in the front panel housing.

EMI Noise Filter Installation

Model 4010 Panels are supplied with two ferrite cores (Figure 2–1) that should be attached to the cables before installation. These cores are required to suppress EMI emissions that are conducted through the power cable and the communications cable. The figure below shows the ferrite cores properly installed. Attach the cores within one inch of the 4010 connector. The cable should be snugly wrapped once around the core, providing two passes through the core.

The power cable core is a solid ferrite cylinder. The power cable should pass once through the core, be looped around and pass through a second time. Pull the excess cable so that it rests snugly against the outside of the core.

The communications cable core is a snap-together, split, ferrite core. This core can be installed on a finished cable. Lift the latch to open the core. Wrap the wire through the core center, snugly around the outside, and again through the center. Close the core until the latch snaps. Ensure that the cable jacket is not pinched between the two halves of the core. The finished cable should look similar to the drawing below.

Figure 2–1. Attaching cores



Mounting

The Model 4010 can be mounted with studs (Figure 2–2) or DIN clips (Figure 2–4). The panel comes with all the necessary mounting hardware required for stud mounting. A mounting template and dimensions are shown in Figure 2–3.

Figure 2–2. Mounting with Studs



Figure 2–3. Mounting Template and Dimensions



Model 4010 Cutout Dimensions (MountingTemplate)

DIN Clip Mounting

DIN clips are metal brackets that attach to the panel housing and secure the front bezel to a mounting surface with a screw (Figure 2–4). They provide an alternative to bolting the panel into the mounting surface. There are 4 square holes in the chassis (two on the top and two on the bottom). Insert the clip flanges into the holes and secure the 4010 Panel by tightening the DIN clip screws until the front bezel is firmly pressed to the mounting surface.





Connections and Wiring

This section describes how to connect the panel to other equipment and provides a connection diagram (Figure 2–5).

Figure 2-5. Model 4010 Rear Panel Connections and Wiring

Rear View



This port may be used to connect the programming computer or a controller. Use a programming cable (PN 4071-CBL) to connect the PC. Use a 2880G adapter and a 2881 cable to connect to your CTC controller.

Power Connector

This block style connector is used to connect an external 24 VDC power supply. The connector with screw terminals is provided with your 4010 Panel and allows you to plug into the power receptacle. A pinout is shown below. An external power supply is adapted to supply operating voltage to the 4010 Panel. The power supply must deliver a range of 20 to 30 VDC.

In multi-panel applications, if separate power supplies are used, please ensure the electrical ground common does not have a great potential difference. In a multi-panel application, the power supply must maintain the specified voltage and current consumption under all conditions (this includes power-up) for each of the individual units.

Pin #	Connection							
1	+V	24 VDC (20-30 VDC)						
2	-V	24 VDC (20-50 VDC)						
3	Chassis Ground							

Connect (+) on the unit to the (+) lead of your power source; (-) on the unit is connected to the (-) lead; and chassis GND (on the unit) is connected to the chassis ground of the cabinet. It is recommended you use a regulated power source isolated from relays, valves, etc.

Serial Port

The Serial Port may be used to connect your panel to a programming computer (PC) or a controller. You will only need to connect to a PC when you initially configure and program the 4010 Panel. The Serial Port is then available for connection to the controller. When you power up the 4010 Panel, it will come up in RUN Mode. While in RUN Mode the Serial Port will only communicate with a controller. To program the panel and have the Serial Port communicate with a PC, you will have to enter the SETUP Mode (see following paragraph).

Connect a Programming PC

To program the 4010 Panel, you must put the panel into SETUP Mode. When the panel is powered up, it will be operating in RUN Mode. (The panel will go through "Self Initialization" before it enters Run Mode — you must wait until this is accomplished before entering Setup Mode.) To enter SETUP Mode, you must press and hold the UP Arrow button while simultaneously pressing the DOWN Arrow button. While in SETUP Mode you may also adjust the screen contrast by pressing the UP/DOWN Arrows.

The 4010 Panel is configured using a PC running the QuickText Panel Programming Software. When you are ready to download the program, connect the programming cable (PN 4071-CBL) to the serial port of the panel and the serial port of the PC. A wiring diagram for the programming cable follows.

Connection Diagrams

Figure 2–6 shows how to connect the 4010 panel to the controller's RS-232 port. Connect your controller to the 4010 Panel with a 2880G adapter and 2881 cable.

Figure 2–6. RS-232 Connections



Learning the Features

Memory Mapping / Controller Data Registers	27
Controller Data Types	27
Pushbuttons	
LEDs	
Annunciator Lamps	29
Controller Message Registers	
Embedded Data Registers	
Controller Messages and Local Messages	
Displaying Controller Messages	
Arrow Adjustment Entry	35
Numeric Keypad Entry	
Annunciator Lamps	
PLC Message LED	
Displaying Local Messages	

This page is intentionally left blank.

Learning the Features

In this section, we will help you to learn and understand the features of the Model 4010 Panels. Details for using pushbuttons, controller messages, LEDs, and local messages are discussed. We recommend that you read this chapter before you attempt to configure and use the 4010 Panel features and controls. As you proceed through this section, relate the topics discussed with how you will implement your panel.

Regardless of the controller type, the concepts discussed here are applicable. To help you, the following figures use small example programs that display instruction elements and address references. Once again, this section is showing concepts for using the panel features.

Memory Mapping / Controller Data Registers

The 4010 Panels communicate with the controller through user-defined controller data registers. Controller registers are assigned during configuration using the QuickText Panel Programming Software. For discrete operations, such as pushbuttons, LEDs, and annunciator lamps, the register bits are accessed by the controller's Quickstep program. The following pages show how the pushbuttons, LEDs, and annunciator lamps are assigned to the controller bit registers.

Controller Data Types

You can access the following controller data types with the model 4010:

CTC Controller Registers: R1 – R65535

Example:

- R1 general purpose register
- R1001 digital output #1
- R8501 analog input #1
- R13002 controller millisecond timer



Notes

- 1. In the model 4010, only 16-bit access is available to the controller's 32-bit registers. CTC strongly recommends that you only use the Model 4010 to access values whose range is 0 65535.
- 2. Refer to the CTC Quick Reference Register Guide for a complete listing of CTC registers. It is available in the Support area of our web site at www.ctc-control.com.

CTC Data Table Locations: D1,1 – D65535,255 (Drow#,col#)

These locations access the controller data table. The actual size of the controller data table is defined in the Quickstep program running on the controller. Only data table locations that exist in the Quickstep program are accessible.

CTC Status: S0-S3

- S0 Reads 1 if Running, 0 if Stopped. Write 1 to start controller, 0 to stop controller.
- S1 Reads 1 if controller in Program Mode. Reads 0 otherwise.
- S2 Reads 1 if controller has a software fault. Reads 0 otherwise.
- S3 Write 1 to Reset controller.

Pushbuttons

Pushbuttons use 32-bit registers or one 16-bit data table location (Figure 3–1). Use bits 0 through 15 of a 32-bit register. (Address must be READ/WRITE)

```
Figure 3–1. BUTTONS (BIT WRITE) PLC WORD — (FROM PANEL)
```

(BITS)

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
NA	NA	NA	ACK F5	ACK F4	ACK F3	ACK F2	ACK F1			ENT	F5	F4	F3	F2	F1

F1-F5 = Function Pushbuttons 1–5

ENT = Enter

▲ \bullet = Arrow UP/DOWN

ACK F1-F5 = Panel acknowledge of controller button release

NA = not used (do not use for other controller program addresses)

Bits 0–7 are set when pressing the corresponding button on the panel.

Bits 8–12 are set when the **Panel Set and PLC Release** option is selected for the corresponding function pushbutton and the release bit for that button is set by the controller in the LED (BIT READ) PLC WORD.

LEDs

LEDs use one 16-bit register or one 16-bit data table location (Figure 3–2). Use bits 0 through 15 of a 32-bit register.

Figure 3-2. LED (BIT READ) PLC WORD - (TO PANEL)

															(BITS)
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
NA	NA	NA	REL F5	REL F4	REL F3	REL F2	REL F1	NA	NA	NA	LED5	LED4	LED3	LED2	LED1

LED1–LED5 = Only used when **By PLC** has been chosen.

REL F1–REL F5 = Used by controller to release a button that is set by the panel.

NA = not used (do not use for other controller program addresses)
Example when using Panel Set & PLC Release Option for a Function Pushbutton:

Operator Presses Button: F1 is set by the Panel (Bit 0 in Button Word). This is a maintained pushbutton to the controller.

PLC Release Button: REL F1 is set by the controller (Bit 10 in LED Word). The controller resets the panel button by setting this bit in the Quickstep program.

Panel Acknowledge Button Release: ACK F1 is set by the Panel (Bit 10 in Button Word). This is the panel acknowledging to the controller that it has reset the button.

Annunciator Lamps

Annunciator Lamps use one 32-bit CTC register or one 16-bit CTC data table location (Figure 3–3). Use bits 0 through 15 of a 32-bit register.

Figure 3–3. ANNUNCIATOR (BIT READ) PLC WORD — (TO PANEL)

(BITS)

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
NA	LAMP 3	LAMP 3	LAMP 2	LAMP 2	LAMP 1	LAMP 1									

LAMP 1 = Left Lamp, Bits 0 and 1

LAMP 2 = Center Lamp, Bits 2 and 3

LAMP 3 = Right Lamp, Bits 4 and 5

NA = not used (DO NOT use for other controller program addresses)

Refer to Table 3–1 to set the bits in your controller's Quickstep program to have the lamps illuminate in a particular color, or not to illuminate at all.

Color	Lam	ip 1	Lam	p 2	Lamp 3			
	Bit 0	Bit 1	Bit 2	Bit 3	Bit 4	Bit 5		
Off	Off	Off	Off	Off	Off	Off		
Red	On	Off	On	Off	On	Off		
Amber	On	On	On	On	On	On		
Green	Off	On	Off	On	Off	On		

Table 3–1. Lamp Color and Bit Settings

Controller Message Registers

The Model 4010 panels have 2 lines of controller message display. Each message line references a user-defined register in the controller. The registers are assigned using the QuickText Programming Software. The panel monitors each register for a value (message number) and display the message associated with the value (i.e., a value of 3 displays message 3).

Embedded Data Registers

Each message can have up to three embedded data values, DATA 1, DATA 2, and DATA 3. Embedded Data Registers are user-defined.

DATA 1 (READ/WRITE)

This is a controller register or data table location that contains the first of three possible embedded data values on a line for the message displayed. DATA 1 can be set as a READ/ WRITE Register allowing the operator to change a data value. It can also be set to READ ONLY. This is the only data value that has this option.



Note

Decimal points are used with keypad entry only, not arrow adjust. The decimal point must be pressed when entering a decimal value.



Figure 3-4. PLC-Controlled Decimal Point

PLC Controlled Decimal Point

This is a register or data table location in the controller for controlling a decimal point within an embedded data value (DATA 1 only). One register holds the value and the other controls the decimal point. The register addresses are assigned from the Message Edit screen as shown in Figure 3–4. This feature only works with keypad entry, not arrow adjust. No ASCII characters are allowed in DATA 1 with a controller controlled decimal point.

DATA 2 (READ ONLY)

This is a controller register that contains the second of three possible embedded data values on a line for the message displayed. You may manually insert a decimal point. The controller address and data type are assigned from the Message Edit screen.

DATA 3 (READ ONLY)

This is a controller register that contains the third of three possible embedded data values on a line for the message displayed. You may manually insert a decimal point. The controller address and data type are assigned from the Message Edit screen.

Controller Messages and Local Messages

Embedded Data

The user message contains the ASCII characters and optional embedded data to be displayed (Figure 3–5). The embedded data can be up to 3 different values — DATA 1, DATA 2, and DATA 3.

Figure 3–5. Embedded Data Entry

EMBEDDED DATA: TYPE KEYSTROKES FROM ANY LOCATION IN THE MESSAGE.								
	DATA 1 (CTL + 1) (READ / WRITE) PLC Address: Data Type: BCD							
D A T	Min: 0 Max: 9999 Access: Read/Write 💌							
Å	Password Protection O Local O PLC							
1	PLC controlled Decimal Point: PLC Address: Format							
D	DATA 2 (CTL + 2) (READ ONLY)							
Ť	PLC Address: Data Type: BCD 💌							
A 2	(Can manually type a decimal point into the data.)							
D	DATA 3 (CTL + 3) (READ ONLY)							
T A	PLC Address: Data Type: BCD							
3	(Can manually type a decimal point into the data.)							

Special characters in the message determine where the embedded data from the registers should go. When programming, each character for DATA 1 values will be represented by a "1" for up to five digits. For example, if you want to display a five digit value from the controller, you will press Ctrl + 1 or F5, five times, and "11111" will display in your message (in red) representing the five digit value.

Only DATA 1's embedded value can be Interactive (READ/WRITE register), meaning that data values will display and can be changed from the message. DATA 2 and DATA 3 are Dynamic (READ ONLY register) meaning that they will display a value, but the value cannot be changed from the message. DATA 2 values are entered into the message by pressing Ctrl +2 or F6, and are represented by a "2" for each numerical digit, displayed in blue. DATA 3 values are entered into the message by pressing Ctrl +3 or F7, and are represented by a "3" for each numerical digit, displayed in green. Again, these values can be up to five digits. Data values are only represented by a "1," "2," or "3" when you are programming the message. The actual values will be displayed on the Model 4010 LCD Display window, or will be blank if no value is present.

Password protection may be used on DATA 1 only and can be local or controller defined. Passwords allow you to prevent unauthorized users from changing a controller register value.

For DATA 1, you can select a minimum and maximum range for the embedded data value. The Maximum is to set an upper limit for the data value and Minimum is to set a lower limit for the data value. This will let the user update the value between the ranges. Data values are incremented or decremented with the UP/DOWN Arrow Buttons, or by using the numeric keypad.

Also for DATA 1, you can choose to have the Decimal Point in the value controlled by the controller, or you can manually insert it in the message.

Message Types

This section discusses the three types of messages: Static, Dynamic, and Interactive.

Static Messages

Static Messages (Figure 3–6) are text displays that have NO embedded data. The Static Message may be displayed when an event or condition becomes true. You will enter the messages using the QuickText Programming Software.

Figure 3-6. Static Message Display



Dynamic Messages

Dynamic messages (Figure 3–7) are text messages that include embedded data. These messages are used to display values from the controller (READ only access to a controller register). This data is information that helps the operator closely monitor and/or control the machine or process.

Figure 3–7. Dynamic Message Display



Data Value update from controller register

Embedded Data Values

Embedded Data Values in messages can be of two types — BCD or Binary. DATA 1 can have a decimal point controlled by the controller or manually inserted. DATA 2 and DATA 3 allow you to manually insert a decimal point. The maximum number of data values per message is three. Data type and decimal points are programmed when configuring the message from the Message Edit screen.

Interactive Messages (with an embedded DATA 1 value, only)

An Interactive Message (Figure 3–8) is commonly used for operator data entry. This type of message is used for changing values that are stored in the controller registers (READ/WRITE access). Typical values are Setpoint, Upper and Lower Limits, etc. Interactive Messages may be configured to enter data using the UP/DOWN Arrow buttons.

Figure 3-8. Interactive Message Display



Passwords

Passwords are used to protect DATA 1 values from being accessed by unauthorized users. When pressing the enter button to select a data value to change, the panel will perform a check to see if there is a password on the data value, and whether it is a locally defined password or defined by the controller. Locally defined passwords are set using the QuickText Programming Software. If there is a password on the data value, the operator will be prompted to enter a password. Once entered, the password allows the operator to edit the data value. If the password is not valid, the operator will receive an "Invalid Password" message and then is prompted again to enter a password. You must program the value of the controller password into the register (defined in the QuickText Programming Software) manually, or with an Interactive Message programmed into the panel file structure.

Displaying Controller Messages

Static Message Operation

To display a Static controller message, you simply put the message number (1-256) in the appropriate controller register. These messages are text only, no embedded data.

Dynamic Message Operation

Dynamic messages are text messages that include embedded data. These messages present the operator with important controller data. You may program message numbers 1–256 to be used as dynamic messages. Dynamic messages may be displayed on either the top or bottom line. The maximum number of digits that may be displayed is five (if Binary data format or four if BCD). Use the QuickText Programming Software to configure dynamic messages. See Section 5, Configuration for more information.

Interactive Message Operation

An interactive message is a text display that allows operator data entry. Use these messages to enter or change values that are stored in controller registers. When the interactive message is displayed, the operator can enter data. Check the controller's installation guide to verify which data formats are supported. Depending on the controller, the data format will be either Binary or BCD (Binary Coded Decimal). Five digits may be entered in a 16-bit register using Binary data format. Four digits may be entered in a 16-bit register using BCD data format. For CTC controllers, you must only use binary format.

Interactive messages are configured within the QuickText Panel Programming Software by embedding a DATA 1 value in a controller message. An interactive message requires that you define the format (Binary or BCD), and decimal point position. There are two types of decimal point placements — PLC controlled and fixed placement (decimal point entered between characters when configuring the message). A controller controlled decimal is only allowed in Data 1 using the keypad entry. Data 2 and Data 3 allow you to enter a fixed point (manually inserted). Two controller registers are used to store controller controlled decimal point values, one for the data value and the other for decimal point control. When the decimal point is controller controlled it must be configured in your controller logic program. For more information, see Chapter 5, Configuration, or your controller Configuration Manual.

Arrow Adjustment Entry

Arrow adjust is often used when minimum and maximum setpoint ranges are required or a setpoint value requires only minor adjustment. These arrow adjustments are only possible using the UP or DOWN Arrow pushbuttons. As you press the UP and down Arrow pushbuttons, the numeric value will increment (up) or decrement (down) one count at a time. (The longer you hold down the button, the faster the count will increase or decrease.) When the adjustment is complete, press the enter pushbutton, and the value will be placed in the data register for display and the bit is set. When the UP/DOWN Arrows are used to increment or decrement a value, the cursor is disabled and will not be visible again until you press enter, esc, or return from a Controller Message. Arrow adjustment does not work when using decimals.

Numeric Keypad Entry

Numeric Keypad entry is used when a decimal point is being used and is the preferred method for data entry instead of arrow adjust. The decimal point button must be used when entering a decimal value.

Annunciator Lamps

There are three tri-color lamps located above the LCD Message Display. They can be illuminated as red, amber or green through the controller program.

PLC Message LED

The PLC Message LED will illuminate any time a controller message is being displayed. Press the esc key to exit the controller message and return to Local Messages. Press esc again to redisplay the last controller message.

Displaying Local Messages

In a Local Message, the first message (root level) or folder in the hierarchy is displayed on the top line at start up and the following message or folder is displayed on the second line.

A plus (+) is displayed in front of a folder's or subfolder's name if it is closed. If a folder or subfolder is open, a minus (-) is placed in front of the name. Any messages within that folder will be displayed below it.

```
+Local Folder 1
+Local Folder 2
-Local Folder 2
Local Message 2.1
```

You may use the UP/DOWN Arrow buttons to scroll down to the next message in that folder. At the end of the messages for that folder, you can press the esc button to move to the previous folder or level.

The Local Message menu hierarchy can only extend three levels deep (after the root level) but each folder (level 1 and level 2) may have many subfolders or messages on that level. Folder level 3 may have many messages, but no folders. Messages can contain up to three embedded data values. See the following examples of a menu tree and how it may appear from within the QuickText Programming Software, and how it may appear on your Model 4010 Panel display.

Figure 3-9. Local Message File Structure Example



Local Message Menu Structure Example

This example resembles what you would see on the Model 4010 Panel Display except that the levels are indented here to make them easier to see.

Viewing the menu from the root (A folder is also counted as a message.)

Local Messages (Root) Message 1 (Root message) Message 2 (Root message) +Folder A (Folder is closed, but it contains 3 messages and two subfolders with 3 messages each) Message 16 (Root message) Message 17 (Root message) +Folder D (Folder is closed, but it contains 5 messages and one subfolder also with 5 messages) Message 29 (Root message)

Viewing the menu from open Folder A

-Folder A (Folder is open and it contains 3 messages and one subfolder with 3 messages) Message 4 (Folder A message) Message 5 (Folder A message)
+Folder B (Folder is closed, but is contains 3 messages and one subfolder also with 3 messages) Message 14 (Folder A message)

Viewing the menu from open Folder B

-Folder B (Folder is open and it contains 3 messages and one subfolder with 3 messages) Message 7 (Folder B message) Message 8 (Folder B message) Message 9 (Folder B message) +Folder C (Folder is closed, but it contains 3 messages)

When a folder is opened, a minus sign "-" appears before the folder name. A "+" sign indicates that the folder is closed.

Local Messages (Root) Message 1 (Root message) Message 2 (Root message) -Folder A (Folder A is open) Message 4 (Folder A message) Message 5 (Folder A message) -Folder B (Folder B is open and is a subfolder of Folder A) Message 7 (Folder B message) Message 8 (Folder B message) Message 9 (Folder B message) -Folder C (Folder C is open and is a subfolder of Folder B) Message 11 (Folder C message) Message 12 (Folder C message) Message 13 (Folder C message) Message 14 (Folder A message) Message 15 (Root message) Message 16 (Root message) +Folder D (Folder D is closed) Message 29 (Root message)

This page is intentionally left blank.

Tutorial

Model 4010 Panel Setup	41
Planning the Project using Application Worksheets	43
Tutorial - Creating the Project using QuickText Programming Software .	
Tutorial – Configure a Controller	57

This page is intentionally left blank.

Model 4010 Panel Setup

SETUP Mode

In order to download the program to the Model 4010 Panel with the QuickText Panel Programming Software, you must be in the Setup Mode (Figure 4–1). Setup Mode is also where you will adjust the 4010's display contrast.

Figure 4–1. Setup Mode Display



The 4010 Panel will start up in the RUN Mode. To access the SETUP Mode, follow these steps:

- 1. Press the **UP Arrow** Pushbutton and hold while simultaneously pressing the **DOWN Arrow** Pushbutton to enter the SETUP Mode.
- 2. At any time you may press the Escape (**esc**) button to go back to RUN Mode. You will be taken back to the start of the Local Message menu (cursor is placed at root level when you return from setup).

Adjust Display Contrast

You may only adjust the Display Contrast when in Setup Mode. To adjust the display contrast use the UP and DOWN Arrows to increase or decrease the contrast.

Internal Software and Hardware Revisions

While in **SETUP** Mode the Panel Hardware Revision, Driver Revision, Boot Revision, and Exec (Firmware) Revision numbers will display on the panel.

Preparing for Configuration

If you prepare and plan ahead of time, your use of the QuickText Panel Programming software will be successful. Below are a few important steps to take to prepare to program your application.

- Prepare your personal computer and ensure proper installation of the QuickText Panel Programming Software
- Know your operator interface requirements such as the number of 4010 Panels required by your application
- Know your controller type and available resources such as programming tools, CPU capabilities, user memory, and so forth.
- Verify type of communications port, as well as protocol used. Determine the CPU link(s) available for connecting a Model 4010 Panel (RS-232/RS-422, baud rate, parity, stop bits.) For CTC, use RS-232, 9600 or 19200 baud, no parity, and 1 stop bit.

- Determine how the pushbuttons, LEDs, controller messages, and local messages will be assigned in your panels with respect to your machine or process.
- To prepare your application, use the application worksheets provided in appendix A of this manual. The example worksheets will help you understand how the 4010 Panel program is configured. Blank worksheets can be used in planning, implementing, and using your 4010 Panels.

Installing QuickText Programming Software

Model 4010 Panels are configured with software running on an IBM or compatible personal computer. This software (PN 4071) is available through Control Technology Corporation. The software is used to download your configuration before connecting the panel and communicating with a controller. Help Topics are provided to help you configure your panel. You design and configure your 4010 Panel program off-line and save it to disk. The program may then be transferred to the Model 4010 Panel. To install QuickText Programming Software, perform the following steps:

- 1. Place the CD into your CD ROM Drive.
- 2. From Windows click on the **Start** Button, and then click on <u>**Run**</u> from the menu. The **Run** dialog box will pop up.
- 3. At the prompt type D:\ (or your CD Drive) setup.exe or click on the **<u>B</u>rowse** Button and find the **Setup.exe** file for QuickText Programming Software.
- 4. Click on the **OK** button to begin the installation. The QuickText Programming Software Installation Screen will appear.
- 5. Follow the onscreen prompts to load the software.

Planning the Project using Application Worksheets

The following is a project tutorial. It will take you through the process of creating a new project, configuring buttons and annunciator lamps, creating messages, and transferring a project to the Model 4010 Panel. This should help familiarize you with the QuickText Programming Software.

Let's start by filling out the application worksheet found in Appendix A. For tutorial purposes, we have already filled in the information. For your project, make copies of the forms in Appendix A. Follow steps 1 through 4 as shown below to fill out the application worksheet for the QuickText Demo Project.

		M	odel 4	010 F	Panel A	oplication Wo	rksheet	
	1	PROJECT NAME: _	Tutori	al				
1. Fill an inf	l in the project d controller ormation.	CONTROLLER CONF Model: 2700 Protocol: CTC Address: Timeout: 30 PANEL TYPE: 4010	IGURAT	ION:		Baud Rate: Parity: Data Bits: Stop Bits: Checksum:	9600 None 8 1	
	2	BUTTONS/LEDS						
2. As wc bu Pa (if PL Bu Se pa	sign a controller ord (R202) to the ttons and to the unel Acknowledge using Panel Set/ LC Release for utton Action). ee the next age.	BUTTON ACTION/P Button Action: (PLC Address) F1 Bit 0 = 1 F2 Bit 1 = 2 F3 Bit 2 = 4 F4 Bit 3 = 8 F5 Bit 4 = 16 LED CONTROL/PLC	Mom.	AIK.	Pnl Set/ PLC Rel *	E (BIT WRITE) P * Panel Act ACK F1 _ ACK F2 _ ACK F3 _ ACK F3 _ ACK F4 _ ACK F5 _ N BIT READ) PLC V	LC WORD knowledge c c. Address) lot Used ot Used it 11 = 2048 lot Used NORD	R202 of PLC Release:
3. As wo LE usi an Re Pa Re Ac	3 sign a controller ord (R201) to the D Control (if ing By PLC) d PLC Button elease (if using nel Set & PLC elease Button tion). See the	LED Control: (PLC Address) LED1 Not Used LED2 Not Used LED3 Not Used LED4 Bit 3 = 8 LED5 Not Used * Pan the Pai	By Button X X X El Ackno nel Set &	By Bur & Flas	e and PLC	* PLC Butt (PI REL F1 REL F2 REL F3 REL F4E REL F5 Button Release and itton Action.	on Release: C Address) ot Used lot Used ot Used it 11 = 2048 lot Used e only used with	hen using

** LED Control by PLC is the only LED function that uses a Controller Address.

This example shows the bit addresses for the Button PLC Word (R202) and LED PLC Word (R201) in this tutorial.



Note

Please note that any unused bit address SHOULD NOT BE USED in your controller program. The 4010 Panel will control the unused bits.

Pushbuttons

Pushbuttons use one 32-bit register or one 16-bit data table location. Use bits 0-15 of a CTC register.

BUTTONS (BIT WRITE) PLC WORD - (FROM PANEL)



MP 1 (BIT 0)	P S (BIT F (PLC Add	READ) PI dresses) (BIT 1) _		D	Rź	203	
MP 2 (BIT 2) MP 3 (BIT 4)		(BIT 3) _ (BIT 5) _					
d Color	Color LAMP 1				LAMP 3	LAMP 3	
S.	ВП 0	ВП 1	ВП 2	ВП 3	ВП 4	ВП 5	
OFF	OFF	OFF	OFF	OFF	OFF	OFF	
Red	ON	OFF	ON	OFF	ON	OFF	
Amber	ON	ON	ON	ON	ON	ON	
Green	OFF	ON	OFF	ON	OFF	ON	
	MP 1 (BIT 0)	(PLC Add VIP 1 (BIT 0) VIP 2 (BIT 2) MP 3 (BIT 4) d Color LAMP 1 BIT 0 OFF OFF Red ON Amber ON Green OFF	(PLC Addresses) VIP 1 (BIT 0) (BIT 1) VIP 2 (BIT 2) (BIT 3) VIP 3 (BIT 4) (BIT 5) d Color LAMP 1 S. BIT 0 BIT 1 OFF OFF OFF Q OFF OFF Green OFF ON Green OFF ON	(PLC Addresses) VIP 1 (BIT 0) (BIT 1) VIP 2 (BIT 2) (BIT 3) VIP 3 (BIT 4) (BIT 5) d (BIT 5) d Ent 0 BIT 1 S. OFF OFF OFF OFF OFF OFF OFF Amber ON ON ON Green OFF ON OFF	(PLC Addresses) MP 1 (BIT 0) (BIT 1) MP 2 (BIT 2) (BIT 3) MP 3 (BIT 4) (BIT 3) J (BIT 5) J (BIT 5) J BIT 0 BIT 1 S. OFF OFF OFF QFF OFF OFF OFF Amber ON OFF ON OFF Green OFF ON OFF ON	(PLC Addresses) (BIT 1) (BIT 1) (BIT 1) (BIT 3) (BIT 3) (BIT 3) (BIT 3) Color LAMP 1 LAMP 2 BIT 0 BIT 1 BIT 2 BIT 3 BIT 0 BIT 1 BIT 2 BIT 3 S. OFF OFF OFF OFF OFF OFF OFF OFF OFF OFF Amber ON OFF ON OFF ON Green OFF ON OFF ON OFF OFF	

Model 4010 Panel Application Worksheet

5. Assign a PLC Word for each controller message line. For the next part of our project planning, we'll create four local messages using the local message worksheet. These messages will be configured later in our QuickText Demo Project using the QuickText Programming Software.



The last part of our project planning is creating three CONTROLLER Messages using the CONTROLLER Message Worksheet. These messages will be configured later in our QuickText Demo Project using the QuickText Programming Software.

1			Μ	odel 4	010) Pa	ane	App	olica	tion	Wo	orks	she	eet					
1. Add message	PLC MESSAG	ES:																	
No. 1. When F3 button on panel	Message No1	F	3	В	U	Т	Т	0	N	Μ	Е	S	S	S A	G	Е			
is pressed, this message will be displayed.			TA 1 BCD PLC	ters Decima	nary al	,					D Mi	Rea Rea n	ad ad/	Only Write Ma	IX		-		
2			TA 2 BCD	Bi	nary		ата] В(.3 CD [Bin	- ary									
2. Add message	Message No 2	Р	L	С	R	Е	L	Е	AS	E		в	I	Т		А	С	К	Ν
No. 2. This message will be displayed to let the operator kno that the controlle has turned off F button on the pa	ow er 4 anel.		charact TA 1 BCD PLC TA 2 BCD	Decima	nary al nary	D		.3 CD [Bin	- - ary	C Mi	Rea Rea	ad ad/	Only /Write _ Ma	ıx				
<u> </u>	Message No3	Е	S	С	F	0	R		LO	С	А	L		М	S	G	S		
 Add message No 3. This message will be displayed when either of the oth messages are displayed to let the operator kn how to return to 	e her ow		tharact TA 1 BCD PLC TA 2 BCD	ters Decima	nary al nary			.3 CD [Bin	- - ary	C Mi	Rea Rea n	ad ad/	Only /Write _ Ma	ıx				

local messages.

Tutorial – Creating the Project using QuickText Programming Software

This procedure assumes that you have the programming software installed on your PC. Connect the Model 4010 Panel to your PC using a programming cable (PN 4071-CBL). Apply 24 VDC to the panel power connector.

- 1. From the Welcome screen, click on the New System button.
- The Create Project window (Figure 4–2) will appear. Type in "QuickText Demo Project" in the File name field. Click on Save. (If you don't want your project saved to the default "Project" folder, navigate to the directory and/or folder where you want it to reside.)

Figure 4-2. Creating a Project



- 3. In **Step 1, Select Panel**, you will start your project by selecting the panel type you are using.
 - a. From the Main Configuration Screen, click on the Select Panel Type button.
 - b. The Select Panel dialog box will open (Figure 4–3). Under Panel Type, click on the panel type you are using to highlight it. A picture of the panel will appear under Panel Preview, and key features of the panel are displayed under Panel Attributes.
 - c. Click on the **OK** button to select, and close the dialog box.

Figure 4–3. Selecting a panel

The Panel View Port Window Help	Ð×
CTC QuickText Main Configuration Screen	
Step Click here to select a panel type, then select Model 4010 from the list of panels.	
Select PLC: CTC 2600 / 2700 - Rev a Select Panel Panel Type: Panel Preview: Model 4010	× -
Select PLC comparation to selected LC	
Configure Panel System Image: Configure Panel System PLC addresses Image: Configure Panel PLC Exit Panel PLC Address database Image: Configure Panel PLC Built in menu system * EMI filtered Power Supply to reduce communication problems OK Cancel	

- 4. In Step 2, Select PLC, you will choose the type of controller you are using.
 - a. Click on the DOWN arrow next to the **Select PLC** field to view the drop-down menu (Figure 4–4). You can use the 2600/2700 protocol for all 2600/2700 series, MultiPro, and 5100 series controllers.

Figure 4–4. Selecting a controller type

Select P <u>L</u> C:	CTC 2600 / 2700 - Rev a	•
	CTC 2600 / 2700 - Revia	

b. Click on the **Press for communication configuration for Selected PLC** button (Figure 4–5).

Figure 4-5. Configuration button



c. The Controller Attributes window (Figure 4–6) will appear for the controller you have selected. Set the attributes to match those in the screen capture below. For 5100 series controllers, use a baud rate of 19200 instead of 9600. Click on the OK button.

Figure 4-6. Controller Attributes

С	TC Attributes			×					
	PLC Editor Revision : a - Communication Paramete Baud Rate Parity Stop Bits Select RS485 Control RTS Require CTS	Second Se	─ Other Parameters Timeout time (1-255) tenths of Second . Poll Time (0-255) tenths of Second.	30					
	OK Cancel Help								

- 5. In Step 3 you will configure the Buttons/LEDs, Messages, Annunciators, and Panel System PLC Addresses.
- Click on the Buttons/LEDS button (Figure 4–7) to display the Buttons/LEDs screen (Figure 4–8).



Messages Annunciator Buttons / Leds
Step 2
Configure Panel System
PLC addresses



Figure 4-8. Buttons/LEDs screen

- a. Under LED Control, click on the down arrow to view control choices. Select By Button for LED 1, LED 2 and LED 3. Select By PLC for LED 4, and By Button & Flash for LED 5 (Figure 4–8).
- Under Button Action, click on the down arrow to view control choices. Select Alternate for F1 and F5, Momentary for F2 and F3, and Panel Set & PLC Release for F4.
- c. Assign PLC Word R201 for the LEDs and R202 for the Buttons.
- d. Click on **OK** to accept and exit the screen.

7. Click on the **Annunciator** button. The Annunciator Setup screen (Figure 4–9) will appear.

Figure 4–9. Annunciator Setup

Annunciator Setup		×
PLC Read Word (Bits) :	R203	
LAMP 1	LAMP 2	LAMP 3
BITO = 0	BIT2 = 0	BIT4 = 0
BIT1 = 0	BIT3 = 0	BIT5 = 0
BITO = 1	BIT2 = 1	BIT4 = 1
BIT1 = 0	BIT3 = 0	BIT5 = 0
BITO = 1	BIT2 = 1	BIT4 = 1
BIT1 = 1	BIT3 = 1	BIT5 = 1
BITO = 0	BIT2 = 0	BIT4 = 0
BIT1 = 1	BIT3 = 1	BIT5 = 1
OK	Cancel	Help

- a. Assign a PLC Read Word (Bits).
- b. Click on OK to accept and exit the screen.
- Next, we'll show you how to configure Local Messages. Click on the Messages button for Step 3 on the Main Configuration Screen. The Message Edit screen will appear (Figure 4–10).

Message edit	×
Step 1 Select Local or PLC Message Type Step 2 Message Text:	TYPE MESSAGE TEXT AND OPTIONAL EMBEDDED DATA: Load Part # 1111 Step 3 Press to accept Message edit Message length: 16
Local Add Local Local Folder Folder Delete	EMBEDDED DATA: TYPE KEYSTROKES FROM ANY LOCATION IN THE MESSAGE.
Local Messages Folder 1 Folder 1 Folder 1 Folder 2 PLC Message Add next PLC Message Delete Number: Delete Delete Number: Delete	PLC Address: R207 Data Type: Binary ▼ Min: 1200 Max: 1999 Access: Read/Write ▼ Image: Password Protection Image: Controlled Decimal Point: PLC PLC Image: PLC Address: Image: PLC Address: Image: PLC Address
Total Number of messages (Df 256) Panel PLC Address Database HELP CANCEL OK	DATA 2 (CTL + 2) (READ ONLY) PLC Address: Data Type: Can manually type a decimal point into the data. 1 DATA 3 (CTL + 3) (READ ONLY) PLC Address: DATA 3 (CTL + 3) (READ ONLY) PLC Address: Data Type: BCD × (Can manually type a decimal point into the data. 1)

Figure 4–10. Message Edit screen

- a. Click on the Add Local Folder button (Step 1). In the Message Text field (Step 2), type in "Process Control." Click on the Press to accept Message edit button (Step 3).
- b. Click on the **Process Control** Folder to select it, and then click on the **Add Local Message** button.
- c. Enter "F1 to toggle Output1" in the Message Text field and then click on the Press to accept Message edit button.
- d. Next we'll configure a Dynamic Message. Click on the Process Control Folder, then click on Add Local Message and type in "Zone 1 Temp =". After Zone 1 Temp =, enter a space and press F5 (or Ctrl +1) three times, type in a decimal point, then press F5 again. Type in a "C" immediately after the "111.1". (DATA 1 will appear as four, red ones in the message.)
- e. Under the **DATA 1** section of the screen shown in Figure 4–11, type in "**R206**" in the **PLC Address** field. The **Data Type** should be set to **Binary**, and **Access** should be **Read Only**.

Figure 4–11. Entering the first message



- f. Click on the Press to accept Message edit button.
- g. The last Local Message to be configured will be an Interactive message (DATA 1).
- h. Click on the Process Control Folder, then click on Add Local Message.
- In the Message Text field, type in "Load Part #", leave a space, and then press F5, or Ctrl + 1, four times. (DATA 1 will appear in the Message Text field as four, red ones).

j. The DATA 1 configuration area is now available (no longer grayed out). Next to PLC Address, type in "R207". Data Type should be Binary. Access is Read/ Write. Set the Min. value to "1200" and the Max. value to "1999" (settings are shown in Figure 4–12). This will limit what value can be entered by the operator.

Figure 4–12. Entering the second message



- k. Click on the Press to accept Message edit button to save it.
- 9. Create PLC Messages 001, 002, and 003 (Figure 4-13) as follows:

Figure 4–13. PLC Messages



- a. Click on the Add next PLC Message button.
- b. Type in the Message Text field, "F3 Button Message".
- c. Click on the Press to accept Message edit button to save it.
- d. Click on the Add next PLC Message button.
- e. Type in the Message Text field, "PLC Release Bit Ackn".
- f. Click on the Press to accept Message edit button to save it.
- g. Click on the Add next PLC Message button.
- h. Type in the Message Text field, "ESC for Local Msgs".
- i. Click on the Press to accept Message edit button to save it.
- 10. Click on OK to exit the Message Edit screen.
- 11. Configure the panel system PLC addresses (main Configuration screen) by clicking on the **Configure Panel System PLC addresses** button.

12. The **Panel System PLC Address Setup** screen (Figure 4–14) will appear. Enter settings as follows:

	Panel System PLC Address Setup				
	PLC Messages (Line Address) Setup:			Password Setup	
Controller Messages Setup	Item	Address	DATA T	/pe	Local Password: 0
	Line One:	R204	Binary	⊡	PLC Password
	Line Two:	R205	Binary		Hegister:
Enable Beeper	Line Three:		BCD	V	Enable Beeper
	Line Four:		BCD	Ð	
					3 PLC Message LED illuminates
	Easy :	essages are as as 1 - 2 - 3		ſ	PLC Message Light
	he	ere's how they w	ork		
		PLC writes the desired n	essage		2 Message 4 is Displayed on line 1.
	[7]	number to the PLC addr assigned to that line.	ess		Programmed Message 4
					* Programmed Message 1 Help for
	YC		alue of 4 to Lin	e 1 PL	* Programmed Message 3 Address * Caddress * Programmed Message 4 Format
	PLC: CTC	C 2600 / 2700 - Rev	a		Help Cancel OK

Figure 4–14. PLC Address Setup

- a. Type in "R204" in the Line One field. Select Binary as the DATA Type. Type in "R205" in the Line Two field. Select Binary as the DATA Type.
- b. The panel beeper is defaulted to **Yes**. If you do not want to hear the beeper each time a button is pressed, select **No** under **Enable Beeper**.
- c. Click on the **OK** button to save and exit.
- 13. You are now ready to write the project to the Model 4010 Panel.

- 14. Click on the Write to Panel button on the Main Configuration Screen.
- The Writing to Panel screen (Figure 4–15) will appear. Click on the down arrow under Port selected and select the COM port on your PC that is connected to the Model 4010 Panel (COM1, COM2, COM3 or COM4).

Figure 4–15. Writing the project to the panel

CTC QuickText	Editor - [sample.ctc]		_ _ X
🛄 File Panel Vie	X Pa 🖻 🎒 🗛 🎗		느먹스
Gontrol Technology Corporation	CTC Quic	kText Main Configuration Scree	n
Step 🚽		Writing to Panel	
Select Panel	Select Pagel Type Model 4010	Clearing memory Writing messages Writing messages COM1 COM1	
Select PLC:	CTC 2600 / 2700 · Rev a	Witing system attributes	
Step 7		Writing PLC driver	
Select PLC	Press for communication configuration for Selected PLC	Writing PLC Attributes	
	Massana Annunistar	0%	
Step 3		Stat Cancel Hep	
Egit .	Panel PLC Address database	Help Write to Panel Bood from Panel	⊻erify

- 16. Before proceeding, ensure that the panel you are about to write to is in the Setup Mode. To enter the Setup Mode, press the UP and DOWN arrows on the 4010 Panel simultaneously. The panel display will read SETUP MODE on the first line.
- 17. Click on the Start button on the Writing to Panel screen (Figure 4-15).
- 18. The progress of the Write to Panel process (Figure 4–16) will be shown by a check mark placed in front of the items as the project is written to the panel. The status bar along the bottom portion of the screen will also show the progress.

Figure 4–16. Writing to Panel progress



19. Now that the panel is configured, let's connect our controller programming software to the controller and write the Quickstep program.

Tutorial – Configure a Controller

For the purposes of this tutorial, we will be using a Model 2700 Series controller. To configure the controller, we are using Quickstep software. The purpose of this part of the tutorial is to show you how to configure your controller to communicate with a 4010 Panel.

This Quickstep program is compatible with any 2600/2700 series, MultiPro, or 5100 series controller where digital I/O is used.

- 1. Connect to the controller with Quickstep.
- 2. Enter the following Quickstep code:

[1]	Start
	<no change="" digital="" in="" outputs=""></no>
	do (Output_1 Output_2 F3_Message Output_3 OI_Mapping) goto Start
[2]	Output_1 ;;; This task turns Ouput 1 On and Off and turns lamp 1 Red or off ;;; according to the value the Model 4010 returns for the F1 key. ;;;
	;;; A value of 1 to the Lamp_1_R215 register will turn it red, ;;; a value of 0 will turn the lamp off.
	Output_1_Off
	store 0 to Lamp_1_R215 if F1_Pressed_R210=1 goto Next
[3]	Turn_Out_1_On Output_1_On
	store 1 to Lamp_1_R215 if F1_Pressed_R210=0 goto Output_1
[4]	Output_2 ;;; This task turns Ouput 2 On and Lamp 2 Green for 5 seconds whenever ;;; F2 is pressed on the Model 4010 operator interface. ;;; Note that F2 should be configured on the Model 4010 as ;;; a momentary push button.
	Output_2_Off
	store 0 to Lamp_2_R216 if F2_Pressed_R211=1 goto Next
[5]	Turn_Out_2_On
	Output_2_On
	store 2 to Lamp_2_R216 delay 5 sec goto Output_2
[6]	F3_Message ;;; This task puts a PLC message on the Model 4010 when ;;; F3 is pressed. The PLC message is indicated by writing ;;; values to the Message registers, which should be configured ;;; as registers 204 and 205 for the Model 4010.
	<no change="" digital="" in="" outputs=""></no>
	if F3_Pressed_R212=1 goto Next

[7] Show_F3_Message _____ <NO CHANGE IN DIGITAL OUTPUTS> _____ store 1 to OI Line 1 R204 store 3 to OI_Line_2_R205 goto F3_Message [8] Output 3 ;;; This task illustrates the Model 4010's PLC release feature. ;;; This works as follows: ;;; Operator presses F4. This is checked in Step 8. ;;; Controller turns output 3 on and the LED for F4. ;;; The controller writes the F4 release bit to clear F4. ;;; The Model 4010 clears the F4 pressed bit when it ;;; recognizes that the release bit is set. ;;; The Model 4010 sets the ACK bit for F4, indicating to ;;; the controller that it is now OK to look for the next ;;; instance of F4 being pressed. Checked in Step 9 -----Output_3_Off _____ store 0 to F4_Release_R223 store 0 to LED4_R221 if F4_Pressed_R213=1 goto Next [9] Turn_Out_3_On _____ Output_3_On _____ store 1 to LED4_R221 store 1 to F4_Release_R223 store 3 to Lamp_3_R217 if F4_ACK_R224=1 goto Next delay 500 ms goto Turn_Out_3_On [10] Wait_for_Out_3_Off _____ <NO CHANGE IN DIGITAL OUTPUTS> _____ store 0 to F4_Release_R223 if F4_Pressed_R213=1 goto OI_Out_3_Off monitor Input_1 goto In_Out_3_Off [11] OI_Out_3_Off _____ _ _ _ Output_3_Off _____ store 0 to LED4_R221 store 1 to F4_Release_R223 store 0 to Lamp_3_R217 if F4_ACK_R224=1 goto Output_3 delay 500 ms goto Turn_Out_3_On [12] In_Out_3_Off _____ Output_3_Off _____ store 0 to LED4_R221 store 0 to Lamp 3 R217 store 2 to OI_Line_1_R204 store 3 to OI_Line_2_R205 goto Output_3

[13] OI_Mapping ;;; This maps the F Keys from the 4010 interface into individual registers ;;; This is done using boolean bitwise operators. For more details on usin ;;; boolean math operators, please see page 3-49 of the ;;; Quickstep Language and Programming Guide. ;;; ;;; After the bits are masked using the boolean operation, we divide by th ;;; bit value, so the resulting register has a value of 0 or 1, instead of ;;; or the bit value. ;;; ;;; Because we are using the PLC release feature of the F4 key, we also ne ;;; to map the acknowledge bit of the button register for use in the Quick ;;; program. ;;; Because F5 is not used in the program, these statements have not been included: ;;; store OI_Buttons_R202 and 16 to F5_Pressed_R214 ;;; store F5 Pressed R214 / 16 to F5 Pressed R214 ;;; _____ <NO CHANGE IN DIGITAL OUTPUTS> _____ store OI Buttons R202 and 1 to F1 Pressed R210 store OI_Buttons_R202 and 2 to F2_Pressed_R211 store F2_Pressed_R211 / 2 to F2_Pressed_R211 store OI_Buttons_R202 and 4 to F3_Pressed_R212 store F3 Pressed R212 / 4 to F3 Pressed R212 store OI_Buttons_R202 and 8 to F4_Pressed_R213 store F4_Pressed_R213 / 8 to F4_Pressed_R213 store OI_Buttons_R202 and 2048 to F4_ACK_R224 store F4_ACK_R224 / 2048 to F4_ACK_R224 goto Next [14] OI_Mapping_2 ;;; This step combines the three registers used for the ;;; annunciator lamps on the 4010 into the single register ;;; used by the 4010 to control those lamps. ;;; ;;; The values for the individual registers and the lamp ;;; color that they represent: ;;; ;;; Off = 0;;; Red = 1 ;;; Green = 2;;; Amber = 3_____ <NO CHANGE IN DIGITAL OUTPUTS> _____ _____ store Lamp_2_R216 * 4 to Temp_R499 store Lamp_3_R217 * 16 to Temp_R498 store Temp_R498 + Temp_R499 to Temp_R499 store Temp_R499 + Lamp_1_R215 to Lamps_R203 goto Next

[15] OI_Mapping_3
 ;;; This step is used to set the LED and Release bits for ;;; F4 in the Model 4010 LED register. ;;; ;;; First, the two bits we are looking at are cleared by the ;;; first store instruction. 2056 is a bitwise representation of ;;; bit 3 and bit 11. The andnot is used to clear only those two ;;; bits in the register. ;;; ;;; The individual registers are then scaled to reflect the ;;; bit values of 8 for bit 3 and 2048 for bit 11. The bitwise ;;; or instruction is used to set these bits when they are a 1. ;;; If the individual bits are 0, the or instruction will not ;;; change them. <NO CHANGE IN DIGITAL OUTPUTS> _ _ _ _ _ _ _ _ _ _ _ _ _ . _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ . _____ store OI Leds R201 andnot 2056 to OI Leds R201 store LED4_R221 * 8 to Temp_R497 store OI_Leds_R201 or Temp_R497 to OI_Leds_R201 store F4 Release R223 * 2048 to Temp R497 store OI_Leds_R201 or Temp_R497 to OI_Leds_R201 goto OI_Mapping

- 3. Save the program to the controller and to disk (QuickText Demo Project).
- 4. Place the controller in Run Mode.

Testing the Project

The controller is now configured and running. Now, to test our project, connect the Panel to controller communications cable (PN 2880G adapter and 2881 cable) to the panel port and the controller port.

- 1. Press the esc (escape) button on the 4010 panel. The Local Message (folder), "- Process Control", will be displayed on the first line.
- Press the enter button to open the folder. Level 2 Local Message "Press F1 to Start Y0" will be displayed. Use the up/down (arrow) buttons to scroll through the messages. Press the esc button to go back to the Folder Level 1.
- 3. Press F1 to turn ON or OFF Output 1, and turn LAMP 1 Red.
- 4. Press F2 to turn ON Output 2 and LAMP 2 Green for 5 seconds.
- 5. Press F3 to display Controller Message No. 1.
- Press F4 to turn ON Output 3 and LAMP 3 Amber. Either press F4 again to turn it OFF, or turn on Input 1 in the controller. If the controller turns OFF F4, a message will be displayed.
- 7. Press F5 to see an alternate button with flashing LED.

CONGRATULATIONS! You have now successfully configured a Model 4010 Panel!

Configuration

Configuration	63
Configure a New System	63
Configure Existing System	
Connect to Panel, View Panel Status and Firmware Version	79
Upgrade Firmware	
Fixing a downloading error	

This page is intentionally left blank.

Configuration

This section describes how to configure a new system, edit an existing system, view panel status, and upgrade the Model 4010's firmware.

Configure a New System

1. Click on the QuickText Editor Icon to open the QuickText Panel Programming Software. The main screen will appear (Figure 5–1).

Figure 5–1. Main QuickText Programming screen

CTC QuickText Editor
File View Port Help
CTC QuickText Main Configuration Screen
Walkares to OTO QuintTart Editor
Vercome to CTC GuickText Ealton Version 1.04
Mew system Existing system View parei status Exit CTC QUICKText & Firmware version & Firmware version Exit CTC QUICKText
Ready

2. Click on the **New System** button to configure the QuickText Panel program. The **Create Project** screen will appear (Figure 5–2).

Figure 5–2. Creating a New Project

Create Project	<u>? ×</u>
Save in: 🔁 EZText	- 🖬 🍋 🖬 -
DI	
Driver Firmware	
Project	
File name:	Save
	Save
Save as type: .ezx	Cancel

3. Enter a name for the project in the **File name** field. Navigate to the directory and folder where you want to keep the file (or except default location), and click on the **Save** button to save. The Configuration screen will appear (Figure 5–3).

Figure 5–3. Configuration screen

🚔 CTC QuickText Editor - [sample.ctc]	- I ×
🎞 File Panel View Port Window Help	_ 8 ×
CTC QuickText Main Configuration Screen	
Select Panel Select Panel Model 4010	
Select PLC: CTC 2600 / 2700 · Rev a	
Step 7	
Select PLC Press for communication configuration for Selected PLC	
Messages Annunciator Buttons / Leds Step 3 Configure Panel System PLC addresses Image: System	
Egit Panel PLC Address database Help Panel	/erify
Ready NUI	М //

4. For **Step 1**, click on the **Select Panel Type** button to display the Select Panel screen (Figure 5–4). Under **Panel Type**, click on the model you are using. A **Panel Preview** and **Panel Attributes** specific to the type of panel you have chosen will appear in this dialog box. Click **OK** to enter your selection.

Figure 5-4. Selecting a panel type

Select Panel		X
Panel Type:	Panel Preview:	
Model 4010		
Panel Attributes: * 2 x 20 with 5 user (* Numeric keypad or * Built in menu syster * EMI filtered Power	defined buttons and LED's • scroll data entry m Supply to reduce communication problems	_
	OK Cancel Help	
5. The Main Configuration screen (Figure 5–5) changes and shows you the 4010 configuration options.

Figure 5–5. Configuration options

	🕂 CTC QuickText Editor - [sample.ctc]	
	🏧 File Panel View Port Window Help	_ 8 ×
	CTC QuickText Main Configuration Screen	
	Step 1 Select Panel Select Pagel Type Model 4010	
	Select PLC: CTC 2600 / 2700 - Rev a	
	Step 2 Select PLC Press for communication configuration for Selected PLC	
Specific to the Model 4010 —	Step 3	
	Configure Panel System PLC addresses	
	Exit Panel PLC Address database Help Write to Panel Yet Panel	nify
	Ready NUM	

6. For Step 2, click on the Down Arrow next to the Select PLC field (Figure 5–6). Choose the controller and Protocol type you are using. MultiPro and 5100 series also use the 2600/2700 series protocol.

Figure 5-6. Select PLC field



 Click on the Press for Communication Configuration for Selected PLC button (Figure 5–7). A Controller Attributes dialog box specific to your type controller will appear (Figure 5–8).

Figure 5–7. Communication Configuration button



Figure 5-8. Attributes screen

C	TC Attributes				X
	PLC Editor Revision : a Communication Paramet Baud Rate Parity Stop Bits Select RS485 Control RTS Require CTS	ers 9600 None No No No		Other Parameters Timeout time (1-255) tenths of Second . 30 Poll Time (0-255) tenths of Second. 0	
)К	Са	ncel Help	

- Complete the communications information. After selecting the controller type, you
 must define the remaining protocol items, such as baud rate, parity, etc. For CTC controllers, use the following settings --Parity: None, Select RS485: No, Control RTS: No,
 Require CTS: No. The baud rate is determined by the controller's baud rate setting.
 The default baud rate for 2600, 2700, and MultiPro controllers is 9600. For the 5100
 series controller, it is 19,200.
- 9. During configuration, ensure that your address and communications parameters match the controller port settings. There will be a selection for controller time-out. When the panel sends a message to the controller and does not receive a response or does not understand the response, it will wait the time-out period before sending the message again. A communication failure initiates the error message "PLC COMMU-NICATION TIMEOUT" on the panel.
- For Step 3, click on the Configure Panel System PLC Addresses button (Figure 5–9). The Panel System PLC Address Setup window will appear (Figure 5–10).

Figure 5–9. Configuring PLC Addresses button



	Panel System PLC Address Setup	×
If you want the controller to turn on the panel — beeper, click Yes here.	PLC Messages are as Easy as 1 - 2 - 3 PLC Message sare as Easy as 1 - 2 - 3 here's how they work Image of the stress	
	YOUR PLC Avalue of 4 to Line 1 PLC address Programmed Message 1 Programmed Message 2 Programmed Message 3 Programmed Message 4 Help for PLC Address PLC: CTC 2600/2700 - Reva Help Cancel OK PLC: CTC 2600/2700 - Reva Help Cancel OK	

Figure 5–10. PLC Address Setup

- Under PLC Messages (Line Address) Setup, enter the controller addresses for Line One and Line Two. Select the Data Type for the controller. Select Yes or No to Enable Beeper.
- 12. If you want Password Protection (Figure 5–11), to restrict access to data entry, enter a Local Password (up to 5 digits, 0–65535). If you want to store the password in the controller, enter a register address (Controller Password Register) and select the Data Type for the controller. Click OK to exit the Setup screen.

Figure 5–11. Password Protection

Password Setup	
Local Password: 0	DATA Type
PLC Password Register:	Binary 💌

13. Next, click on the **Buttons/LEDs** button (Figure 5–12) to configure the Panel Functions. The Buttons/LEDs screen (Figure 5–13) will appear.

Figure 5–12. Buttons/LEDs button





Figure 5–13. Buttons/LEDs screen

14. First select the LED Control for Button F1 (Figure 5–14). You may choose to have the LED controlled By Button, By Button & Flash, or By PLC. Make selections for Bit 0 through Bit 4. The LED function depends on the type of Button Action selected.

Figure 5-14. LED Control pull-down menu



- By Button means that the LED illuminates when the button is pressed.
- By Button & Flash means that the LED illuminates and flashes when the button is pressed.
- By PLC means that the LED illuminates when triggered by the controller.
- 15. Select the **Button Action** for each button Bit 0 through Bit 4 (Figure 5–15). You may choose from **Momentary**, **Alternate**, or **Panel Set and PLC Release**.

Figure 5-15. Button Action pull-down menu



- Momentary means that the Button is ON only while the button is being pressed.
- Alternate means that the Button it turned ON when the button is pressed and only turns OFF when the button is pressed again.

- **Panel Set and PLC Release** means that the Button is turned ON when the button is pressed and turns OFF when pressed again or when turned off by the controller.
 - PLC Button Release Bits use Bits 8 through 12 (Decimal). If the button is ON, the controller can release the button by setting the corresponding release bit.
 - Panel Acknowledge of PLC Release Bits use Bits 8 through 12 (Decimal). The panel turns ON these bits to acknowledge the PLC Release Bits.
- 16. Enter a LED (Bit Read) PLC Word and a Buttons (Bit Write) PLC Word address (Figure 5–16).

Figure 5–16. LED and PLC Word Addresses

This register controls LEDs and PLC Button Release (read-only or	
read/write).	LED (Bit <u>R</u> ead) PLC Word: R201
This register controls	Buttons (Bit Write) PLC Word: R202
Buttons and Panel Acknowledge (must be read/write).	*

- 17. Click on **OK** to save your Button/LED control selections.
- 18. Now you are ready to configure the Annunciator Lamps. Click on the **Annunciator** Button (Figure 5–17). The Annunciator Setup screen (Figure 5–18) will appear.

Figure 5–17. Annunciator Button



Figure 5–18. Annunciator Setup screen



- Enter a controller address in the PLC Read Word (Bits) field. When you configure the controller's Quickstep program, use the bit assignments as shown in Figure 5–18 to control the three annunciator lamps. (White represents OFF.)
- 20. Click on the **OK** button to save the register address and exit the screen.
- 21. Now you are ready to configure Local and PLC Messages. Click on the Messages button (Figure 5–19). The Message Edit screen (Figure 5–20) will appear.





Figure 5–20. Message Edit screen

	Message edit
Click here to add a folder.	Add Add Insert Insert Local
Click here to add a message.	Image: Docal Messages Image: Docal Messages Image: Docal Prices Fl to Start YO Image: Docal Prices Fl to Start YO Image: Docal Part # 1111 Image: Docal Part # 1111 Image: Docal Part # 1111 Image: Docal Part # 1111 Image: Docal Part # 1111 Image: Docal Part # 1111 Image: Docal Part # 1111 Image: Docal Part # 1111 Image: Docal Part # 1111 Image: Docal Part # 1111 Image: Docal Part # 1111 Image: Docal Part # 1111 Image: Docal Part # 1111 Image: Docal Part # 1111 Image: Docal Part # 1111 Image: Docal Part # 1111 Image: Docal Part # 1111 Image: Docal Part # 1111 Image: Docal Part # 1111 Image: Docal Part # 1111 Image: Docal Part # 1111 Image: Docal Part # 1111 Image: Docal Part # 1111 Image: Docal Part # 1111 Image: Docal Part # 1111 Image: Docal Part # 1111 Image: Docal Part # 1111 Image: Docal Part # 1111 Image: Docal Part # 1111 Image: Docal Part # 1111 Image: Docal Part # 1111 Image: Docal Part # 1111 Image: Docal Part # 1111 Image: Docal Part # 1111 Image: Docal Part # 1111 Image: Docal Part # 1111 Image: Docal Part # 1
	D - DATA 2 (CTL + 2) (READ ONLY) PLC Address: Data Type: BCD Y (Can manually type a decimal point into the data.) D Total Number PLC Address: Data Type: Or messages 6 PLC Address: Data Type: D A A CANCEL OK A Can manually type a decimal point into the data.) Data Type: BCD Y

- 22. For Step 1, choose to configure a Local or PLC Message. Local Messages are messages stored in the panel in a menu hierarchy and provide information and instructions to the operator. PLC Messages are triggered by a value in a controller register. The PLC Message LED will illuminate to tell the operator that the controller has triggered a message. The buttons will not respond for 3 seconds after the PLC Message has been triggered to ensure that the operator has a chance to read the message. See step 23 to program a PLC Message. To program a Local Message, perform the following steps.
 - a. Next to Local Messages, click on the Add Local Folder button or the Add Local Message Button (Figure 5–20).
 - b. Under Step 2, type in up to 20 characters in the Message Text field.
 - c. **Step 3**, click on the **Press to Accept Message Edit** button. The message text you have typed in will appear in the Local Message field (Figure 5–21).



Figure 5–21. Entering a local message

Note

Folders can have a maximum of 19 characters.

d. If you want to embed data from a controller register in a Local Message, place the cursor in the message where you want the value to appear and press F5 or (CTRL+1) for Data 1, F6 or (CTRL+2) for Data 2, or F7 or (CTRL+3) for Data 3. Each press of the function key will enter one data value digit. You may enter up to 5 characters (depending on the data type). In the message, the data will be represented by red 1's for DATA 1, blue 2's for DATA 2, and green 3's for DATA 3 (Figure 5–22). The actual value will display in the message on your Model 4010 Panel.

Figure 5–22. Representation of data

EM TY	BEDDED DATA: PE KEYSTROKES FROM ANY LOCATION IN THE MESSAGE.
	DATA 1 (CTL + 1) (READ / WRITE)
	PLC Address: Data Type: BCD 💌
D A	Min: 0 Max: 9999 Access: Read/Write 💌
A	Password Protection C Local C PLC
1	PLC controlled Decimal Point: PLC Address: Format
D	DATA 2 (CTL + 2) (READ ONLY)
A T	PLC Address: Data Type: BCD 💌
A 2	(Can manually type a decimal point into the data.)
D	DATA 3 (CTL + 3) (READ ONLY)
T	PLC Address: Data Type: BCD 💌
3	(Can manually type a decimal point into the data.)

Note

Data 1 is READ/WRITE and allows the option for the operator to change data values in the controller register using the Control Keys on the Model 4010 Panel. Data 2 and Data 3 are READ ONLY and will display a value from the controller register. You cannot change the DATA 2 or DATA 3 value from the panel.

e. Now you will need to configure the embedded data (Figure 5–23). If you have embedded data, you will notice that the DATA 1, DATA 2, or DATA 3 field is now available.

Figure 5–23. Embedded Data

EM TY	BEDDED DATA: PE KEYSTROKES FROM ANY LOCATION IN THE	MESSAGE.
D A	DATA 1 (CTL + 1) (READ / WRITE) PLC Address: R207 Data Typ Min: 1200 Max: 1399 Access: Re	oe: <mark>Binary </mark> ad/Write v
Ä	Password Protection C Local	C PLC
1	PLC controlled Decimal Point: PLC Address:	Help for PLC Address Format

- f. You must first enter the **PLC Address** where the value resides. Select the Binary **Data Type** (format) for your CTC controller.
- g. Select the Access for the controller register. Will you want the message to display a register value (READ only)? Do you want the message to display a register value and allow the operator to change the value with the numeric keypad (READ/ WRITE)?
- h. If you select **READ/WRITE** Access, you can enter a **Minimum** and **Maximum** Range that the operator can write to the controller.
- Select whether or not to enable Password Protection for this data value. Select Local or PLC. Passwords are entered by the operator with the numeric keypad. The operator will not be able to change the data value if the correct password is not entered.
- j. You may configure DATA 1 to display a decimal point that is controlled by the controller. The location of the decimal point must be configured in your Quickstep program. Place a check mark in the box next to PLC Controlled Decimal Point and then enter the PLC Address where the control resides. (This is DATA 1 only you cannot configure PLC Control for a DATA 2 or DATA 3 embedded value.) Keypad entry, not arrow adjust, must be used when using decimals.

Figure 5–24. Local Message 1111



k. If PLC control for the decimal point is enabled, the program will place a decimal point at the end of the characters representing the data value in the Message Text field — 1111. in Figure 5–24. Then placing a value of 1–4 (BCD) or 1–5 (Decimal) in the controller register will place the decimal in the appropriate location.

I. You may manually enter a decimal point in DATA 1, DATA 2 or DATA 3, by placing your cursor in the message where you want it to appear in the value, and then insert the decimal point as shown in Figure 5–25.

Figure 5–25. Local Message 222.22

Message Text:	Local	Message	222.22

m. Create Folders to group messages relating to the same topic. The first message or folder you program will appear on the first line of the Model 4010 Panel display when it is in Run Mode. (Second programmed message displays on second line, etc., up to four lines, depending on the type of panel you are using.) The Local Message and Folder menu tree can have up to 3 levels as shown in Figure 5–26.

Figure 5–26. Local Message and Folder Menu tree

Local	Add	Add	Insert Inse	ert	1			
Messages	Folder Message	Local Message	Local Messages	Add Local Folder	Add Local Message	Insert Folder	Insert Message	Delete
			🖃 🔤 Local	Message	28			
		🗄 💼 Process Control 1						
			📙 👘 P	rocess	Control	2		
			Process Control 3					
J								
				E, nes	saye on	тут		

- n. To add a folder, click on the Add Local Folder button.
- To insert a Message or Folder between already configured messages, you must first have a message or folder highlighted. Click on **Insert Folder** or **Insert Mes**sage. The inserted Message or Folder will be placed above the highlighted Message or Folder.
- p. To delete a Message or Folder, click on it to highlight it and then click on the **Delete** button.
- q. To save your messages, click on the **OK** button at the bottom of the **Message Edit** window. To exit without saving, click on the **Cancel** button.
- 23. **PLC Messages** are triggered by a value in a controller register. The PLC Message LED (Figure 5–27) will illuminate to show the operator that the controller has triggered the message. To program a PLC Message, click on the **Add Next PLC Message** button.
 - a. Type in text up to 20 characters in the Message Text field. The 20 character maximum includes Data Items, also, if you choose to enter them. You will see the Message Length value change as you enter characters to let you know how many you have used. The current Message Number and Total Number of Messages (of 256) programmed are also displayed for your information (Figure 5–28).

PLC Message LED PLC lights and indicates fault overtemp run 7 8 9 that the panel is displaying a Tool 'A' Selected System Running 4 5 6 controller-triggered message. 1 2 3 0 ce F2 F3 F1 F4 **F**5

Figure 5–27. PLC Message LED



	Message edit Step 1 Select Local or PLC Message Type Message Text	Load Part # 1111
To configure a controller message out of sequence, click in the message number field	Local Add Local Folder Inset Folder Messages Delete Folder 1 Fold	EMBEDDED DATA: TYPE KEYSTROKES FROM ANY LOCATION IN THE MESSAGE. -DATA (CTL + 1) (READ / WRITE) PLC Address: R207 Data Type: Binary Min: 1200 Max 1999 Access: Read/Write Password Protection PLC address: Read/Write PLC Address: Read/Write P
message number. The total number of configured messages is shown here.	Total Number chanacsage (0f 256) PlC Address Database HELP CANCEL OK	DATA 2 (CTL + 2) (READ DNLY) PLC Address: Data Type: BCD Y (Can manually type a decimal point into the data.) DATA 3 (CTL + 3) (READ ONLY) PLC Address: Data Type: BCD Y (Can manually type a decimal point into the data.)

- b. If you want to embed data values from a controller register in the message, press F5 or (Ctrl+1) for DATA 1, F6 or (Ctrl+2) for DATA 2, or F7 or (Ctrl+3) for DATA 3. Each press of the function key will enter 1 data value character. You may enter up to 5 characters depending on the data type you have selected.
- c. You will configure Data 1, Data 2, and Data 3 values the same way as described in a Local Message.

d. If you have configured messages out of sequence and you want to insert a message between messages already programmed, click on **Insert a PLC Message**. Be aware that blank messages count in the Total Messages allowed. For example, you have programmed PLC messages numbered 001, 002 and 004, skipping PLC Message number 003 (Figure 5–29).

Figure 5–29. Out of sequence messages



e. Click on **004:** PLC Message 4 in the message field to highlight it, and then click on the Insert a PLC Message button. PLC Message Number 003 will appear above PLC Message Number 004 and you may enter the new message (Figure 5–30).

Figure 5–30. Inserting a PLC Message



f. Be aware that when programming messages out of sequence, that the "blank" messages are counted in the Total Messages allowed. The "CAUTION" message in Figure 5–31 will appear when you enter a message number higher than the next number in sequence.



EZText	×
৾	CAUTION: When changing a message number to a higher number, all unused lower message numbers will be sent as "blank" messages when the program is transferred to the panel. Blank messages will be counted as part of the maximum allowable messages (256 total)
	Proceed?
	Yes <u>N</u> o

g. If you have skipped more than one message number (e.g., you have programmed messages 1 through 4, skipped messages 5, and 6, and then programmed 7), and highlight message 7 and click on Insert a PLC message, the dialog box in Figure 5–32 will appear asking you to enter the number (e.g., 5 or 6) of the message you want to insert.

Figure 5-32. Inserting out of sequence messages

Insert Message		X
F 1 1 1 1 1	6	OK
Enter a message number between 4 and 7:	E	Cancel

- h. To delete a message, click on it to highlight and then click on the **Delete** button.
- 24. To view the controller addresses you have programmed, click on the Panel PLC Address Database button. The window in Figure 5–33 will open. Shown here will be the addresses mapped to the panel display lines (Line one, Line two, etc.), the Bit Write (Buttons), Bit Read (LEDs), Bit Read (Annunciator Lights), PLC Password Register or Local Password, and the PLC Message Data Items. (Items grayed out are not available for the Model 4010). The controller you have selected and the Project Name are also displayed, along with the Total Number of messages (OUT OF 256) programmed. This is for information only—to edit the addresses, click on the EDIT PANEL SYSTEM PLC ADDRESSES button.

Figure 5-33. Viewing PLC addresses

View PLC addresses				×
ltem	Panel System F	LC Addresses		
Line one	R20 820	4		EDIT PANEL
Line three		-		PLC ADDRESSES
Line four				
Bit Read (LED's)	R20	1		
Bit Write (Buttons) Bit Read (Annuncia	ator Lights) R20	3		
PLC Password Reg	jister:			
Local password:	0			
ITEM No.	Address	Used in Messag	Function	Access
1	R206 R207	Local	Data 1 Data 1	B B AW
2	11201	2000	Data I	
•				Þ
Project PLC(s)/contro	ollers(s):	CTC 2600/27	'00 - Rev a	
Project	Name:	Sample	.ezx	
Total Number of me	ssages (OUT OF 256)		4
	Print	DK Help		

25. Click on the **Print** button to print the database or the **OK** button to exit.

Configure Existing System

Configure an existing system as follows:

1. Click on the QuickText Editor Icon to open the QuickText Programming Software; the main programming screen will appear (Figure 5–34).

Figure 5–34. Main Programming screen

CTC QuickText Editor	
File View Port Help	
CTC QuickText Main Configuration Scree	n
with the Control Technology Corp exclusive "Easy as 1- 2 - 3" programming systems.	
Welcome to CTC QuickText Editor Version 1.04	
& Firmware version	
4	►
Ready NUM	1.

2. Click on the **Existing System** button to edit an QuickText Panel program. The Open dialog box (Figure 5–35) will appear.

Figure 5–35. Opening an existing project

Open			? ×
Look in: 🔁 My Docum	ients	- 🗧 🛨	
Backup Bookmarks CTC Stuff Downloads Episode_14_Preview	My Music My Pictures Purchases Visual Capture Web website	ia) Sample.ezx ia) Sample2.ezx	
File name:			Open
Files of type: .ezx		•	Cancel

- 3. Select the project you want to edit from the default program directory or navigate to where the project resides. Click on it to highlight, and then click on the **Open** button and the project you have selected will open to the Main Configuration Screen.
- 4. Begin editing your project.

Connect to Panel, View Panel Status and Firmware Version

Click on the **Connect to Panel, View Panel Status & Firmware Version** button to view the panel status. The **Panel Status** window will open. An example is shown below (Figure 5–36).

Figure 5-36. Panel and Controller information



Upgrade Firmware

There may be occasional upgrades to the Model 4010 Panel internal software, also referred to as the Exec or Firmware. Check Control Technology's web site at www.ctc-control.com periodically for information about software and firmware upgrades.

Upgrade firmware as follows:

- 1. Place the panel in **Setup Mode** by pressing the UP/DOWN arrows on the 4010 Panel simultaneously.
- 2. Under the **Panel Menu**, click on **Upgrade Firmware**. The Upgrade Firmware screen will appear (Figure 5–37).

Figure 5–37. Upgrade Firmware screen

Upgrade firm w are	x
Select firmware file The firmware upgrade file is usually named as CTCxxxxYd.hex (xxxx represents the panel model and Yd represents the firmware revision i.e. CTC4010A1.hex). Please select CTCxxxxYd.hex (or the file under which you have saved the firmware upgrade file).	
(Firmware will be generally stored under Browse \CTC QuickText\firmware directory)	
CAUTION Loading the firmware will replace the current firmware in the panel and the user program in the panel will be lost when the firmware is updated. Press OK to continue.	
OK Cancel Help	

 Click on the Browse button. The window in Figure 5–38 will open to the default folder Firmware (located in the QuickText Program directory). If the firmware file has been downloaded from CTC's web site at www.ctc-control.com and moved to another location, navigate to the new firmware file (.hex file).

Figure 5-38. Opening a firmware file

Open		? ×
Look in: 🔁 Firmware	▼ 🗧 🖻 🖛	
A CTC401011.hex		
File name:	Оре	۱
Files of type: Firmware Files (*.hex)	▼ Canc	el



Note

The firmware file is called **CTC4010xy.hex**. The "x" represents the major revision of the firmware (e.g., A). "y" represents the minor revision (e.g., 1).

 Select the appropriate COM port under Port Selected (if necessary) and click on the Start button to begin downloading the firmware to the Model 4010 Panel (Figure 5–39). A status bar will let you know when the upgrade is complete. Click on Close when complete.

Figure 5–39. Downloading firmware

DownLoading Firmware	×
Clearing memory Writing messages Writing Map Data Writing system attributes Writing PLC driver Writing PLC Attributes	Port selected:
Start Cance	el Help

- 5. When you initialize the **Upgrade Firmware** process, the Model 4010 Panel Message display will read **SELF TESTING**. When the download begins, the display will read **LOADING EXEC**. When the download is complete, the panel will enter Run Mode.
- 6. If the message INCOMPATIBLE EXEC is displayed on the panel while the Upgrade is in process, it means that the wrong firmware file has been sent to the panel. You will also receive an error message from the QuickText Programming Software. If this happens, follow the procedure outlined on the top of the next page.

Fixing a downloading error

- 1. Click on the **OK** button on the Error Message.
- 2. Click on the Cancel button on the Downloading Firmware window.
- 3. Click on **Upgrade Firmware** to start the process over, being careful to select the correct firmware.hex file.



Notes

- 1. When you upgrade firmware and press the Start button, the panel will display **SELF TESTING** while the upgrade is initializing.
- 2. When the download begins, the panel will display LOADING EXEC.
- 3. The message **INCOMPATIBLE EXEC** indicates that you have sent the wrong firmware file. Exit all windows, start the Upgrade Firmware process again, and make sure you select the correct file.

Maintenance and Troubleshooting

Maintenance	. 85
Fuse Reset	. 85
Precautions	. 85
Screen Overlay / Chemical Compatibility	. 85
Screen Overlay Cleaning	. 87
Gasket Replacement	. 87
Troubleshooting	. 88
Panel Configuration Problems	. 88
Controller Errors	. 89
Pushbuttons, LEDs, and Messages	. 89
Frequently Asked Questions (FAQs)	. 90
Controller Errors Pushbuttons, LEDs, and Messages Frequently Asked Questions (FAQs)	. 89 . 89 . 90

This page is intentionally left blank.

Maintenance

Fuse Reset

The Model 4010 Panel features an AUTO-RESET fuse (0.65 Amp polyfuse). It is reset by removing power for 5 minutes and then reapplying power to the unit.

Precautions

To ensure the longevity and effectiveness of the 4010 Panel, please take note of the following precautions:

- Do not press sharp objects against the pushbuttons or screen overlay.
- Do not strike the panel with hard objects.
- Do not press the pushbuttons or screen overlay with excessive force.
- Once the panel is mounted and has power applied, do not place any objects over the ventilation slots. This will result in heat buildup and may damage the unit.

Screen Overlay / Chemical Compatibility

The screen overlay has a polycarbonate surface. The following list is provided to make you aware of the general compatibility between chemicals that may be present in your work environment and the polyester surface of the overlay. Use the chart to determine those chemicals that are safe to use around your 4010 Panel and those that may harm the overlay. The list rates these chemicals as **E**—**Excellent**, **G**—**Good**, **F**—**Fair**, and **N**—**Not Recommended**. Because the ratings are for conditions at 134 °F (57°C), consider all factors when evaluating your application.

RATING	CHEMICAL	RATING
Ν	Ammonium Hydroxide @ 5%	Ν
N	Ammonium Hydroxide @ 30%	N
G	Ammonium Oxalate	E
G	Ammonium Salts	G
N	n-Amyl Acetate	N
N	Amyl Chloride	N
N	Aniline	N
E	Benzaldehyde	N
N	Benzene	N
F	Benzoic Acid	G
N	Benzyl Acetate	G
G	Benzyl Alcohol	G
E	Bromine	F
N	Bromobenzene	N
E	Bromoform	N
F	Butadiene	N
	RATING N N G G N N E N E N G E N F	RATINGCHEMICALNAmmonium Hydroxide @ 5%NAmmonium Hydroxide @ 30%GAmmonium OxalateGAmmonium OxalateGAmmonium SaltsNn-Amyl AcetateNAmyl ChlorideNAmyl ChlorideNAnilineEBenzaldehydeNBenzeneFBenzoic AcidNBenzyl AcetateGBenzyl AlcoholEBromineNBromobenzeneEBromoformFButadiene

CHEMICAL	RATING	CHEMICAL	RATING
n-Butyl Acetate	Ν	Ethylene Oxide	Ν
n-Butyl Alcohol	F	Fluorides	E
sec-Butyl Alcohol	F	Fluorine	F
tert-Butyl Alcohol	F	Formaldehyde	
Butvric Acid	N	Formaldehyde @ 40%	G
Calcium Hydroxide	N	Formic Acid @ 3%	G
Calcium Hypochlorite	N	Formic Acid @ 50%	G
Carbazole	N	Formic Acid @ 99%	F
Carbon Disulfide	N	Fuel Oil	Ġ
Carbon Tetrachloride	N	Gasoline	F
Cedarwood Oil	F	Glacial Acetic Acid	N
	N	Glycerin	F
Chlorine @ 10% in air	G	n-Hentane	G
Chlorine @ 10% moist	F	Hexape	N
Chloroacetic Acid	N	Hydrochloric Acid @ 5%	F
n Chloroacettonhonono	N	Hydrochloric Acid @ 20%	L E
Chloroform	N	Hydrochloric Acid @ 20%	N
Chromic Acid @ 10%	N	Hydrofluoric Acid @ 59%	
Chromic Acid @ 50%	N	Hydrofluoric Acid @ 48%	N
Cinnamon Oil		Hydrogon Porovida @ 5%	
	r C	Hydrogen Peroxide @ 378	
	G N	Hydrogen Peroxide @ 30%	
Cycloboxano	G		G
Decalin	N	Isopropyl Acetate	G N
	N		
n Dichlorobonzono	N	Isopropyl Renzono	
Diothyl Bonzono	N	Korosopo	
Diethyl othor	N	Lactic Acid @ 2%	G
Diethyl Ketone	N	Lactic Acid @ 85%	G
Diethyl Malonato	N	Mathayyathyl Olasta	N
Diethylene Glycol	F	Methol Alcohol	F
Diethylene Glycol Ethyl Ether	N	Methyl Ethyl Ketone	N
Dimethylformamide	N	Methyl Isobutyl Ketone	N
Dimethyl Sulfoxide	N	Methyl Propyl Ketone	N
	F	Methylene Chloride	N
Dipropylene Glycol	F	Mineral Oil	G
Ether	N	Nitric Acid @ 10%	G
Ethyl Acetate	N	Nitric Acid @ 50%	F
Ethyl Alcohol	G	Nitric Acid @ 50%	N
Ethyl Alcohol @ 40%	G	Nitrobenzene	N
Ethyl Benzene	N	n-Octane	F
Ethyl Benzoate	N	Orange Oil	, E
Ethyl Butyrate	N		G
Ethyl Chloride Liquid	N	Perchloric Acid	N
Ethyl Cyanoacetate	N	Perchloroethylene	N
Ethyl Lactate	N	Phenol Crystals	N
Ethylene Chloride	N	Phosphoric Acid @ 5%	F
Ethylene Glycol	F	Phosphoric Acid @ 85%	C C
Ethylene Glycol Methyl Ether	N	Pine Oil	9 F
Lanyione Orycon Meanyr Luiler	IN I		L

CHEMICAL	RATING	CHEMICAL	<u>RATING</u>
Potassium Hydroxide @ 1%	Ν	Sulfuric Acid @ 60%	F
Potassium Hydroxide conc.	Ν	Sulfuric Acid @ 98%	Ν
Propane Gas	Ν	Sulfur Dioxide Liquid	G
Propylene Glycol	F	Sulfur Dioxide dry	G
Propylene Oxide	F	Sulfur Salts	N
Resorcinol sat.	F	Tartaric Acid	G
Resorcinol @ 5%	F	Tetrahydrofuran	N
Salicylaldehyde	F	Thionyl Chloride	N
Salicylic Acid Powder	G	Toluene	N
Salicylic Acid sat.	G	Tributyl Citrate	N
Salt Solutions Metallic	E	Trichloroethane	N
Silver Acetate	G	Trichloroethylene	N
Silver Nitrate	E	Triethylene Glycol	G
Sodium Acetate sat.	G	Tripropylene Glycol	G
Sodium Hydroxide @ 1%	N	Turpentine	N
Sodium Hydroxide @ 50%+	N	Undecyl Alcohol	F
Sodium Hypochlorite @ 15%	F	Urea	N
Stearic Acid Crystals	G	Vinylidene Chloride	N
Sulfuric Acid @ 6%	E	Xylene	N
Sulfuric Acid @ 20%	G	Zinc Stearate	E

Screen Overlay Cleaning

The Model 4010 Panel screen should be cleaned as needed with warm, soapy water.

Gasket Replacement

The gasket may need to be replaced if it becomes damaged or worn. To replace the gasket perform the following steps:

- 1. The gasket is removed and replaced from the back of the unit. Ensure that all pieces of old gasket have been removed from the panel enclosure surface where the gasket is affixed.
- 2. Remove the new replacement gasket from its plastic bag.
- 3. Remove the temporary protective covering from the adhesive side of the gasket.
- 4. Position gasket (adhesive side down) over the panel gasket surface and press firmly.

Troubleshooting

In this section we will explain how to isolate potential problems. If you cannot isolate and remedy the problem using the procedures we have outlined below, call Technical Support. For a list of Model 4010 Panel, QuickText Programming Software, and CTC Controller Driver Error Messages, see Appendix C.

Panel Configuration Problems

QuickText Panel Programming Software is used to create panel applications and to download/ upload panel programs. If you are online with the 4010 Panel and communication fails, the following error message (Figure 6–1) is displayed:



EZText	×
	Error C009: Time out Error.
	Make sure Panel is in Setup Mode. To enter Setup Mode, press the up and down arrow keys simultaneously.
	ОК

If you receive this QuickText Panel Programming Software error message, check the following:

- On the rear panel of the unit, observe Serial Port Communication TXD/RXD LEDs while attempting to Upload/Download a program. Both LEDs should be slowly and alternately flashing to indicate that the programming PC and the panel are connected. If the TXD (transmitter) LED is the only one flashing, or if the TXD/RXD LEDs are NOT alternating between flashes, check to ensure that the 4010 Panel is set to the Setup (programming) Mode. (To enter the Setup Mode, press and hold the UP Arrow Button while simultaneously pressing the DOWN Arrow button.)
- 2. Check to ensure that the programming cable (PN 4071-CBL) is properly connected at both ends.
- 3. Check that the correct communications port is selected with the QuickText Programming Software (i.e., COM1, COM2)
- 4. Check the 24 VDC power source and its connections.
- 5. After completing steps 1 through 4, above, repeat the procedure to Upload/Download a program.

Controller Errors

If you experience communication problems between the Model 4010 Panel and your controller, you will receive an error message. Look in Appendix C of this manual, or the QuickText Panel Programming Software Help for error messages for your type PLC. The CTC Help topic lists the error messages and provides an explanation for the CTC driver. To access the Help topics, perform the following steps.

- 1. Run QuickText Panel Programming Software.
- 2. From the Main Menu, click on Help > Help Topics.
- 3. Under the **Contents** tab, find the controller you are using (next to a closed book icon) and click on it to view help topics.
- 4. Click on Driver Errors Topic.

Pushbuttons, LEDs, and Messages

You may also notice that the **Pushbuttons**, **Pushbutton LEDs**, and/or **Messages** are not working. Check the following:

- 1. Observe the TXD and RXD LEDs on the rear of the panel. If both LEDs are not steadily flashing or illuminated (depending upon the baud rate) check to ensure the proper communications cable is connected securely at both ends.
- 2. Check the controller communication information for the controller type, protocol, baud rate, parity, stop bits, and address number.
- 3. If you have configured your own cable, verify the cable pinout using the Controller Wiring diagrams provided in Appendix B.
- 4. Check the 24 VDC power source.
- 5. If connected to a multiplexer, connect the panel directly to the controller port.
- 6. Verify that the Model 4010 Panel registers are mapped correctly. Does the 4010 Panel register exist in the controller? Is the register read-only? Is the register write-only?

Frequently Asked Questions (FAQs)

- 1. **Can I connect multiple panels to a single controller?** Yes, you can connect one panel per serial port on the CTC controller.
- 2. What is the maximum number of messages I can have in a project? The maximum amount of PLC and Local messages is 256.

3. What are Local Messages?

A Local Message is a text message that is used to provide instructions or information to the machine operator using a hierarchical file structure. The operator can scroll through these messages using the arrow keys to find information pertaining to a particular part of a process.

4. What are PLC Messages?

A PLC Message is a text message that can be triggered by the controller to provide the operator with important instructions, information, or warnings. PLC Messages will be displayed for 3 seconds before they can be cleared in order to make sure the operator has a chance to read the message. The operator can also view the last PLC Message displayed by pressing the ESC key.

5. How many characters can I have per message?

The maximum number of characters per message is 20. This is true for all messages except folder names. They are limited to 19 because of the plus "+" or minus "-" sign displayed in front of the folder name.

6. What is the maximum number of Embedded Data values I can have in a project? The maximum number of Embedded Data values in a project is 300.

7. How do I get my panel into Setup Mode?

To get the panel into Setup Mode press and hold the up arrow key while simultaneously pressing the down arrow key. To exit Setup Mode, press the **ESC** key.

8. How do I get my panel to display PLC Messages?

To display a PLC message, using your Quickstep program, place the number of the PLC Message you wish to display into one of the PLC Message Line Addresses. When the message number is placed in this register the panel will display the message corresponding with that number.

Example: I want to display PLC Message One on Line One of my panel display. Using the Quickstep program, I write a value of 1 to register 201, which is set as PLC Message Line Address One. The panel displays PLC Message One on Line One of my panel display. The message will remain on the display until the **ESC** key is pressed.

9. Why won't the panel display the same PLC Message twice in a row on the same message line?

This is because the message line must be reset by either setting the Line Register to zero, or by changing the value in the Line Register to some unused PLC Message number.

10. Why do PLC Messages not clear when the ESC key is pressed?

The panel locks out all key presses for 3 seconds after a PLC Message is displayed in order to ensure the operator has a chance to read the message. Pressing **ESC** 3 seconds after the PLC Message is displayed will display the Local Message screen.

11. Does the Model 4010 panel support discrete addresses?

No. All addressing for the 4010 Panels must be in Word format.

12. How do I insert a PLC Message?

In order to insert a PLC Message, there must be a gap in the message numbers. For example, I have PLC Message #1 and PLC Message #3 programmed. If I click on PLC Message #3 and click the INSERT A PLC MESSAGE button, PLC Message #2 will be inserted between PLC Messages 1 and 3.

13. Can I renumber PLC Messages?

Yes, you can renumber PLC Messages; however, when changing a message number to a higher message number, all unused lower message numbers will be sent as "blank" messages when the project is transferred to the panel. Blank messages will count towards the maximum number of allowed messages in a project (256).

14. Can you copy and paste messages?

Yes, you can copy and paste messages. Currently, however, you can copy or paste only one message at a time. (This may be changed to multiple message and folders in the future).

15. It is hard to read the display on my panel. It's too bright. Is there a way to adjust the contrast?

Yes, to adjust the contrast on the display, simply place the panel into Setup Mode. While in Setup Mode you can use the up and down arrow keys to adjust the contrast.

16. What protocol do I use for my MultiPro or 5100 series controller?

All CTC controllers can use the CTC 2600/2700 protocol. This includes the MultiPro and 5100 series controllers.

This page is intentionally left blank.

Application Worksheets

This page is intentionally left blank.

Worksheets

This appendix contains worksheets for buttons and LEDs, annunciators, PLC messages, and local messages.

Model 4010 Panel Application Worksheet

PROJECT NAME: _____

CONTROLLER CONFIGURATION:	Baud Rate:
Model:	Parity:
Protocol:	Data Bits:
Address:	Stop Bits:
Timeout:	Checksum:
PANEL TYPE:	

BUTTONS/LEDS

BUTTON ACTION/PANEL ACKNOWLEDGE (BIT WRITE) PLC WORD _____

Del Catl

Button Action:

* Panel Acknowledge of PLC Release:

				Phi Set/
	(PLC Address)	Mom.	Alt.	PLC Rel *
F1				
F2		ā	ā	ā
F3		ō		ō
F4		ā		ō
F5		ā		ō

	(PLC Address)	
ACK F1		
ACK F2		
ACK F3		
ACK F4		
ACK F5		

LED CONTROL/PLC BUTTON RELEASE (BIT READ) PLC WORD _____

LED Control:

* PLC Button Release:

(PLC Address)	By Button	By Button & Flash	PLC **		(PLC Address)
(PLC Address) LED1 LED2 LED3 LED4				REL F1 REL F2 REL F3 REL F4	
LED9				KEL FO	

* Panel Acknowledge and PLC Button Release are only used when using

the Panel Set & PLC Release Button Action.

** LED Control by PLC is the only LED function that uses a Controller Address.

ANNUNCIATOR:

ANNUNCIATOR LAMPS (BIT READ) PLC WORD

 (PLC Addresses)

 LAMP 1 (BIT 0)
 (BIT 1)

 LAMP 2 (BIT 2)
 (BIT 3)

 LAMP 3 (BIT 4)
 (BIT 5)

Color	LAMP 1		LAMP 2		LAMP 3					
	ВП 0	ВП 1	ВП 2	ВП 3	BIT 4	ВП 5				
OFF	OFF	OFF	OFF	OFF	OFF	OFF				
Red	ON	OFF	ON	OFF	ON	OFF				
Amber	ON	ON	ON	ON	ON	ON				
Green	OFF ON		OFF	ON	OFF	ON				

PLC Messages (PLC Words)

Line 1____

Line 2_____

LOCAL MES	SAGE	S:																	
Folder						Τ	Γ												
🗋 Message						Fol	der –	19 c	haraci	ers	Mess	ane -	- 20 (hara	cters				
Level:				Тл	1	101		150	naraci	1013,	wic55	age -	- 20 (ad (John		
1234					י								-				Jilly Maita		
			Ы	BC	ים. הם	ш В ecim	inary al	/							in Re	au/v	M	; 2V	
				т L,	0 D	Conn	<u> </u>			۸ p				111				<u></u>	-
					ע ע		inon	, I		 		Bing	ari/						
				ЪС	יש		inary	/ 1				Diric	ai y						
Folder						Τ													
Message				<u> </u>	-	Fol	der =	19 c	haract	ters,	Mess	age =	= 20 (chara	cters			<u> </u>	
Level:			DA	TA	1							-			Re	ad C	Dnly		
1234				BC	D	DВ	inarv	,					_		Re	ad/V	Vrite	è	
			ā	PL(C D	ecim	al _							M	in		M	ax _	_
			DA	TA	2			[A 3_									
				вс	D	В	inary	,	В	CD		Bina	ary						
D Folder					_			_										_	
						Fol	der =	19 c	haract	ters,	Mess	age	= 20 (chara	cters				
Level: 1 2 3 4			DA	ΔTA	1								-		l Re	ad C	Dnly		
				вС	DI	∎в	inary	/							Re	ad/V	Vrite	;	
				PL(CD	ecim	al _							Μ	in		M	ax _	-
			DA	TA	2_			[DAT	۹3 <u></u>									
				BC	DI	В	inary	/	B	CD		Bina	ary						
Folder				—		<u> </u>												<u> </u>	
Message																			
Level:						Fol	der =	19 c	haract	ters,	Mess	age :	= 20 (chara	cters				
1 2 3 4			DA	ΛTΑ	1								-		Re	ad C	Dnly		
				BC	D	В	inary	/							Re	ad/V	Vrite	;	
				PL(υD	ecim	al _							Μ	in		_ M	ax _	-
			DA	TA	2_			[A 3_									
				BC	DI	В	inary	/ I	B	CD		Bina	ary						

LOCAL MES	SAGE	S:																		
Folder							Τ	Т	Т		Т	Τ				Γ				
Message						Fo	lder =	- 19	chara	octers	Mes	sage	= 20	chara	cters			L		ł
Level:			ΓΔΠ	ΓΔ 1	1			- 10	onare		mot	ouge	- 20			ad (July			
1234					יי ר ר		inar								Re	Abec.	Mrite	`		
				PLC) De	ecim	nal	у						м	in	<i>au</i> / v	M	, ax		
				TA 2	>				DA	TA 3			-				-		-	
					 ר ר		inar	v		BCI		Bin	- arv							
								у 											 	
Folder Message																				
						Fo	lder =	= 19	chara	cters	Mes	sage	= 20	chara	cters					J
Level:			DAT	TA 1	I										Re	ead (Dnly			
1204				BCI		В	inar	y							Re	ad/\	Vrite	;		
				PLC	De	ecim	nal _						_	Μ	in _		M	ax _	_	
			DAT	TA 2	2				DA	ТА З			_							
				RCI	ר ר		inor				、 —	D'.								
				-01			mar	y		BCI		IBIN	ary							
Folder							Inar	y T		BCI		I Bin	ary	-				<u> </u>		1
FolderMessage								y		BCI		Bin	ary							
 Folder Message Level: 						Fo	lder =	у = 19	chara		Mes	sage	ary = 20	chara	Icters					
 Folder Message Level: 1 2 3 4 			DAT	TA 1		Fo	lder =	y = 19	chara	acters	Mes	sage	ary = 20	chara	icters Re	ead (Dnly			
 Folder Message Level: 1 2 3 4 					I	Fol	Ider =	у = 19 У	chara	acters	Mes	sage	e = 20	chara	Icters Re Re	ead (Dnly Vrite))		
 Folder Message Level: 1 2 3 4 				TA 1 BCI PLC	I D [Fol Becim	Ider = inar	у = 19 У	chara		Mes	sage	e = 20	chara	Icters Re Re in	ead (Dnly Vrite	e ax _	_	
 Folder Message Level: 1 2 3 4 				TA 1 BCI PLC	1 D [2	Fol Becim	inar inar nal	y = 19 'y	Chara DA	TA 3	Mes	sage	= 20	chara	Icters Re Re in	ead (Dnly Vrite	e ax _	_	
 Folder Message Level: 1 2 3 4 				TA 1 BCI PLC TA 2 BCI	I D [C De 2 D [Fol Becim	inar inar nal inar	y = 19 	Chara DA	TA 3	Mes	IBIN	= 20 	chara C M	Re Re Re	ead (Dnly Vrite	e ax _	_	
 Folder Message Level: 1 2 3 4 Folder 				TA 1 BCI PLC TA 2 BCI	I Determined to the second seco	Fo Becim	inar inar inar	y = 19 7y Ty	Chara DA	TA 3 BCI	Mes		= 20 - - ary	chara	I Re Re Re	ead (Dnly Write	, ax _	_	1
 Folder Message Level: 1 2 3 4 Folder Message 				TA 1 BCI PLC TA 2 BCI	1	Fo Fo B B C C C C C	Inar Ider = Inar Inar Inar Inar	y = 19 y y = 19	Chara DA	TA 3 BCI) Mes		ary = 20 - - ary = 20	chara M	Ree	ead (ead/\	Dnly Vrite _ M	e e ax _	-]
 Folder Message Level: 1 2 3 4 Folder Message Level: 4 - 2 4 4 				TA 1 BCI PLC TA 2 BCI	I	Fo Fo B B C C C C C C C C C C C C C C C C C	Inar Ider = Inar Inar Ider =	y = 19 Ty Ty = 19	DA Chara	TA 3 BCI BCI	Mes	IBIN sage	ary = 20 - - ary = 20	chara M	cters Re Re Re Re	ead (ead/\	Dnly Vrite _ M	ax _	-	
 Folder Message Level: 2 3 4 Folder Message Level: 2 3 4 				TA 1 BCI PLC BCI BCI	I D [2 D [I D [Fo	Ider = inar inar inar inar inar	y = 19 Ty Ty = 19	DA chara	TA 3 BCI) Mes	I Bin	ary = 20 - - ary = 20	chara M	I Re Re Re Re Re Re	ead (ead/\	Dnly Write _ M	e ax _	-	
 Folder Message Level: 1 2 3 4 Folder Message Level: 1 2 3 4 				TA 1 BCI PLC TA 2 BCI TA 1 BCI PLC	I D [] D [] D [] D [] D [] D [] D [] D []	Fo	inar inar inar inar inar inar	y = 19 y y = 19 y y	Chara DA	TA 3 BCI BCI	Mes	I Bin	ary = 20 - - ary = 20	chara M chara	I Ree Ree I Ree I Ree Ree I Ree	ead (ead/\ ead (ead/\	Dnly Vrite _ M Dnly Vrite _ M	e ax _	_	
 Folder Message Level: 1 2 3 4 Folder Message Level: 1 2 3 4 				TA 1 BCI PLC TA 2 BCI BCI BCI BCI PLC	I D [D [D [D [D [D [D [D [Fo	Inar Ider = inar inar Ider = inar	y = 19 7y Ty = 19	DA chara	TA 3 BCI Dacters) Mes		ary = 20 - ary = 20 - ary = 20	chara M Chara M	I Re Re Re Re Re Re Re in	ead (ead/\ ead (ead/\	Dnly Write _ M	e ax _	-	

PLC MESSAG	SES:																			
Message No																				
	20 (chara	cters		-			-												
	DA	TA	1										Rea	ad O	nly					
		BC PLC	D C De	Bir Bir	nary al							D Mir	Rea า	ad/W	/rite Ma	x				
	DA	TA	2			C	ΑΤΑ	3_										•		
		вс		Bi	nary	C	В	CD	Œ	Bina	ry									
Message		<u> </u>	T				<u> </u>		<u> </u>							<u> </u>	<u> </u>		_	
No	20 (chara	cters																	
	DA	TA	1										Rea	ad O	nly					
		вс		Bir	nary								Rea	ad/W	/rite					
		PL(C De	cima	al							Mir	n		Ма	x		-		
	DA	TA 2	2			D	ΟΑΤΑ	A 3_												
		BC	DC	Bi	nary		B	CD		Bina	ry									
Message		Γ					Γ													
NO	20 (chara	cters																	
	DA	TA	1										Rea	ad O	nly					
		BC PLC	D D De	Bir Bir	nary al							D Mir	Rea า	ad/W	/rite Ma	IX		_		
	DA	TA :	2			D	ΑΤΑ	۸3										-		
		BC		Bi	nary	C	В	CD		Bina	ry									
Message		<u> </u>	Τ																	
No	20.0	chara	cters																	
	DA	TA	1										Rea	ad O	nly					
		вс		Bin	nary								Rea	ad/W	/rite					
		PLC	C De	cima	al							Mir	ח		Ма	x				
	DA	TA 2	2			D	ΟΑΤΑ	A 3_												
		вС		Bir	nary	٦,	В	CD		Bina	ry									

	GES.															
Message				П												
No	20 characters															
	DATA 1		_		Rea	id O	nly									
	BCD Binary	,			Rea	nd/W	/rite									
	PLC Decimal		-	Min	۱ <u> </u>		Ma	ıx	-							
	DATA 2	DATA 3	-													
	BCD Binary	BCD Bina	ary													
	· · · · · · ·								 	 						
Message No																
	20 characters				D											
			_		Rea		niy									
				Min	кеа	10/V	/rite Ma	1Y								
		DATA 3	-	IVIII			IVIC	<u> </u>	-							
	BCD Binary		- arv													
)													
Message				Π												
NO	20 characters		-						 -	 						
	DATA 1		_		Rea	id O	nly									
	BCD Binary	,			Rea	ld/W	/rite									
	PLC Decimal		-	Min	۱ <u> </u>		Ма	IX	-							
	DATA 2	DATA 3	-													
	BCD Binary		ary													
Message			T	П				<u> </u>	<u> </u>							
No	20 characters															
	DATA 1		_		Rea	id O	nly									
	BCD Binary	,			Rea	id/W	/rite									
	PLC Decimal		-	Min	۱ <u> </u>		Ма	ıx	-							
	DATA 2	DATA 3	-													
	BCD Binary	BCD Bina	ary													
PLC MESSA	GES:															
----------------	----------	------------------	------------------------	----	-------	---	------	----	-----------------	----------	------	-------------	----	---	---	--
Message No																
	20 chara	cters														
	DATA 1									Rea	ad O	nly				
		D 🗖 E C Decir	Binary mal <u> </u>						D Mir	Rea n	ad/W	/rite Ma	IX			
	DATA	2		DA	TA 3											
	🗖 BC		Binary		BCD		Bina	ry								
Message No.				Τ		Т	Γ									
	20 chara	cters					-		_	_			_	-	_	
		1								Rea	ad O	nly				
		D 🖬 E Decir	Binary mal						Mir	Rea n	ad/W	/rite Ma	ıx		-	
	DATA	2		DA	TA 3.											
	🗖 BC		Binary		BCD		Bina	ry								
Message				Т		Т	Γ									
NO	20 chara	cters												-		
	DATA	1								Rea	ad O	nly				
		D 🗖 E Decir	Binary mal <u> </u>						D Mir	Rea	ad/W	/rite Ma	ıx		_	
	DATA	2		DA	TA 3											
	🗖 BC		Binary		BCD		Bina	ry								
Message						Т										
NO	20 chara	cters					-							-		
	DATA	1								Rea	ad O	nly				
		D 🗖 E C Decir	Binary mal <u> </u>						D Mir	Rea	ad/W	/rite Ma	ıx			
	DATA	2		DA	TA 3											
	🗖 ВС		Binary		BCD		Bina	ry								

Model 4010 Panel Application Worksheet

Wiring Diagrams

Panel to Controller Connection Diagram	
Panel to PC Connection Diagram	

Wiring Diagrams

This section has wiring diagrams that show panel to controller and panel to PC connections.

Panel to Controller Connection Diagram

Figure B–1 shows connections between the controller's COM port and the Model 4010 display.

Figure B-1. Model 4010 Panel Communications Cable RS-232 (P/N 2880G and 2881)



Panel to PC Connection Diagram

Figure B–2 shows connections between the PC's COM port and the Model 4010 display.

Figure B–2. QuickText Panel Programming	Cable	(P/N	4071-CBL)	1
---	-------	------	-----------	---



Communication Connector (J1, D-sub 15-pin female)

This table lists the connections for Figure B–2.

Pin #	Connection
1	Chassis GND
2	PLC TXD (RS-232)
3	PLC RXD (RS-232)
4	+5V (100
5	Logic GND
6	LE (DO NOT CONNECT)
7	PLC CTS (RS-232)
8	PLC RTS (RS-232)
9	RD+ (RS-422)
10	RD- (RS-422)
11	SD+ (RS-422)
12	SD- (RS-422)
13	Termination Resistor (connect to pin 9)
14	NC
15	NC

Error Messages

CTC Driver Error Messages	109
Model 4010 Panel Error Messages	110
QuickText Programming Software Error Messages	111

CTC Driver Error Messages

The following section lists the most common error messages for the CTC driver.

PLC Timeout

Reason:	The controller does not respond to the Model 4010.
Solution:	Check the communication settings on the 4010 and the CTC controller. Make sure that the communications cable is properly installed.

Invalid Register Read

Reason:	An invalid register number is specified in the project file.
Solution:	Check the register number in your project file and change it to the correct number.

Value Out of Range

Reason:	An invalid data table location is specified in the project file.
Solution:	Check the data table location in your project file and change it to the correct location.

Model 4010 Panel Error Messages

READ ONLY VALUE

This message indicates that the operator has tried to edit to a read only data item.

INVALID

This message indicates that the operator has entered an illegal password.

NO DATA SET

This message indicates that the operator has tried to enter a data item in a message that contains no data items.

OUT OF RANGE

This message indicates that the operator has entered a value in a data item that is out of range.

QuickText Programming Software Error Messages

Error Codes are divided into categories and are numbered with prefixes and 3 digits as follows:

PLC DLL ErrorsPxxxCommunications ErrorsCxxxTag ErrorsTxxxMessage ErrorsMxxxMiscellaneous ErrorsZxxx

PLC DLL Error Messages

Error P001: Load DLL Procedure failed. Unable to validate PLC address. Possible reason: Unable to locate correct PLC DLL.

Reason: A PLC .dll file has been moved or deleted from the program directory.

Solution: Reinstall the software.

Error P002: Unable to load library: PlcUtils.dll Error P003: Unable to load PLC DLL. Error P004: Unable to unload PLC DLL. Error P005: PLC DLL load failed.

Reason: Unable to load selected PLC DLL.

- Solution: 1. Try closing all other applications and retry.
 - 2. Reboot the system.
 - 3. Reinstall the software.

Error P006: PLC1 is not compatible with PLC2. Do you want to change the PLC anyway?

Error P007: Unable to rebuild the address for new PLC.

Reason: When changing controllers, check the addressing in the controller's installation guide to see if they are compatible (same addressing type is followed in both controllers). If they are not compatible, then the database is no longer valid and the addresses will have to be reentered.

Communication Error Messages

Error C001: The panel connected to the PC is different from the configured one.

- **Reason:** When writing to the panel, if the panel type selected does not match the panel that the computer is physically connected to, the program loader will not upload the project.
- Solution: Select the appropriate panel type for the connected panel.

Error C002: Cannot Locate the Driver File

- **Reason:** Driver file (*.plx) has been moved or deleted from the program directory.
- Solution: Reinstall the software.

Error C003: Error opening port

- **Reason:** Either you have not selected a valid COM port available on your computer or some other program is using this port.
- **Solution:** Select another available COM port or close the program that is using this COM port. If this does not work, reboot your system and try again.

Error C004: Error in setting communication attributes

- **Reason:** Unable to set the attributes for the Panel to PC communication.
- **Solution:** Reboot the system.

Error C005: Unable to write to Panel. Possible cause: No local messages configured.

- **Reason:** No local messages are configured. At least one local message should be configured before downloading the program to the panel.
- Solution: Configure local messages.

Error C006: Error in reading the project from the panel. Project in the panel is corrupted.

Solution: Please upload the project from the computer to the panel. You cannot read the project from the panel.

Error C007: Invalid Length in Reply

Reason: Length of the panel reply buffer is less than the maximum replay length (70)

Solution: If you receive this error message consistently, please report it to Technical Support.

Standard Reply Error Messages

Error Code	Error Message
1	Error C008: Checksum error
2	Error C009: Time out Error. Make sure Panel is in Setup Mode. To enter Setup Mode,
	press the up and down arrow keys simultaneously
3	Error C010: Invalid Message Code
4	Error C011: Start Load Not Requested
5	Error C012: Start Dump Not Requested
6	Error C013: Insufficient space in Text Panel
7	Error C014: Invalid Message Number
8	Error C015: Invalid Message Length
9	Error C016: The firmware being loaded into the panel does not match the panel type
10	Error C017: E2 Memory failed to program correctly
11	Error C018: Invalid Load Format
12	Error C019: Invalid LED control
13	Error C020: Option Not included
14	Error C021: Memory is Read Only
21	Error C022: Invalid with Random PLC loaded
22	Error C023: Invalid with Random/standard format
24	Error C024: Invalid Byte in the data fields of Command

PLC Address Error Messages

Error T001: PLC Address count exceeds maximum limit.

Solution: You cannot assign another controller address. Only 300 controller addresses can be defined. If you want to assign a new address, delete one or more addresses and try again.

Error T002: Invalid Access Type

- **Reason:** Access type of the specified address is invalid (e.g., entering a READ only address where a READ/WRITE address type is expected.
- Solution: Supply the correct address.

Error T02_1: Invalid Unit Number Error T02_2: Invalid Address Type Error T02_3: Invalid Address Error T02_4: Invalid Bit Number Error T02_5: Address in not Word Aligned (Even address is required) Error T02_6: Address is not Word Aligned (Odd address is required)

- Reason: Address entered for the controller address is not correct.
- Solution: Specify a valid controller address.

Error T003: The value entered is invalid.

- Reason: The value entered for Minimum or Maximum field is out of range.
- Solution: Supply values in the range 0...9999 for BCD and 0...65535 for Binary

Error T004: Unable to open tag map file: <filename> Please choose the map file Error T005: Unable to open map file <map file>

- **Reason:** Think N Do map (.map) file not found
- Solution: Locate the correct map file.

Error T006: Error in reading controller addresses

- **Reason:** Unable to generate controller address while reading from the panel.
- Solution: Project in the Panel is corrupted. Reload the project to the panel.

Error T007: Unknown access type specified for controller address

- Reason: Invalid access type found while reading a project from disk.
- Solution: Project in the Panel is corrupted. Reload the project to the panel.

Message Error Messages

Error M001: Unable to add a new Message/Folder. Possible cause: All the available 256 messages have been programmed

Solution: Delete one or more messages or folders and try adding your message again.

Error M002: Invalid message number or this message number has already been configured.

Solution: Please change the message number to a valid message number and ensure that this message number was not programmed earlier.

Error M003: Cannot add a message with message number greater than 256.

Solution: Message numbers have to be numbered with the range of 1 to 256. Please enter a valid message number within this range.

Error M004: Invalid Message Number

Solution: Valid range for message number is 1 to 256. Please enter a valid message number.

Error M005: Message number is out of range

Solution: Message number is out of range. Valid range is 1-256

Miscellaneous Error Messages

Error Z001: Error in printing page

Solution:1. Check whether you have printer attached to the PC and set to Ready.2. If you are still receiving this error, reboot the system and check printer to PC connection.

Error Z002: You are trying to read from an invalid file

- Reason: Either project file is corrupted or you are trying to open an non-QuickText file.
- Solution: If the project file is corrupted, then, recreate the project.

Error Z003: The file may be corrupted

- **Reason:** The Exec file is corrupted.
- **Solution:** If you receive this error message consistently, please report this to Technical Support.

Error Z004: Unable to open the controller driver file

Reason: Invalid controller driver file.

Solution: If you receive this error message consistently, please report this to Technical Support.

Error Z005: The Maximum message length has been exceeded

Reason: Maximum message length exceeded.

Solution: Reduce length of message.

Error Z006: Unknown value type encountered while loading project. Known values are 0 (BCD) and 1 (Binary)

Reason: Invalid value type found while reading project from disk.

Solution: Project file in the panel is corrupted. Reload the project to the panel.

Error Z007: Discrete addresses are not allowed here

Reason: Discrete addresses are not allowed in the QuickText Panel.

Solution: Use the correct address type.

Error Z008: Invalid Device Type

Reason: The connected equipment may not be an QuickText Panel.

Solution: Ensure that you are connected to an QuickText Panel.

Error Z009: Error in project file Line: <line number> Column: <column number> <filename>

Reason: The project file (XML version) is invalid.

Solution: Use a valid project file.